Canon

PowerShot A1200

Camera User Guide

- Make sure you read this guide, including the “Safety Precautions” section, before using the camera.
- Reading this guide will help you learn to use the camera properly.
- Store this guide safely so that you can use it in the future.


ENGLISH

Checking the Package Contents


Check if the following items are included in your camera package.
If anything is missing, contact the retailer where you purchased the camera.



Camera



AA Alkaline Batteries (x2)



Interface Cable IFC-400PCU



Wrist Strap WS-800



Getting Started



DIGITAL CAMERA Solution Disk



Warranty System Booklet

Using the Manuals

Also refer to the manuals on DIGITAL CAMERA Manuals Disk.

- **Camera User Guide (This Guide)**
  Once you have mastered the basics, use the camera's many features to shoot more challenging photos.
- **Software Guide**
  Read when you want to use the included software.



- A memory card is not included.
- Adobe Reader is required to view the PDF manuals. Microsoft Word/ Word Viewer can be installed to view the Word manuals (required only for manuals for the Middle East).

Test Shots and Disclaimer

Take some initial test shots and play them back to make sure the images were recorded correctly. Please note that Canon Inc., its subsidiaries and affiliates, and its distributors are not liable for any consequential damages arising from any malfunction of a camera or accessory, including memory cards, that results in the failure of an image to be recorded or to be recorded in a way that is machine readable.

Warning Against Copyright Infringement

The images recorded with this camera are intended for personal use. Do not record images that infringe upon copyright laws without the prior permission of the copyright holder. Please be advised that in certain cases the copying of images from performances, exhibitions, or commercial properties by means of a camera or other device may contravene copyright or other legal rights even if the image was shot for personal use.

Warranty Limitations

For information on your camera's warranty, please refer to the Canon Warranty System Booklet supplied with your camera. For Canon Customer Support contacts, please see the Warranty System Booklet.

LCD Monitor (Screen)


- The LCD monitor is produced with extremely high-precision manufacturing techniques. More than 99.99% of the pixels operate to specification, but occasionally non-performing pixels may appear as bright or dark dots. This is not a malfunction and has no effect on the recorded image.
- The LCD monitor may be covered with a thin plastic film for protection against scratches during shipment. If so, remove the film before using the camera.

Camera Body Temperature

Please take care when operating the camera for an extended period as the camera body may become warm. This is not a malfunction.

What Do You Want to Do?

Shoot



- Shoot, leaving it to the camera to make settings 23
- Just take pictures (Easy mode) 28

Take good people shots


Portraits (p. 64)


Kids and pets (p. 65)


At the beach (p. 65)


Against snow (p. 66)

Shoot various other scenes

Landscape (p. 65)


Low Light (p. 65)

Foliage (p. 65)

Fireworks (p. 66)

Shoot with special effects


Fish-eye Effect (p. 69)


Miniature Effect (p. 70)


Toy Camera Effect (p. 71)



Monochrome (p. 72)


Super vivid colors (p. 69)


Poster Effect (p. 69)


- Shoot in Discreet mode 68
- Adjust image settings when shooting (Live View Control) 67
- Focus on faces 23, 64, 94
- Shoot in places where I cannot use the flash (turn off the flash) 54
- Take pictures with me in them too (self-timer) 58, 60, 76
- Insert the date and time into my shots 57

View




- Look at my pictures 26
- Easy playback (Easy Mode) 28
- Automatically play back pictures (slideshow) 112
- Look at my pictures on a TV 116
- Look at my pictures on a computer. 32
- Quickly search pictures 110, 111
- Erase pictures 27, 120

Shoot/View Movies




- Shoot movies 29
- View movies 31

Print




- Easily print pictures 132

Save



- Save images to a computer 32

Other



- Turn off sounds 47
- Use the camera abroad 37, 149
- Understand what is displayed on the screen 163

Table of Contents

Chapters 1 – 3 explain the basic operations and frequently used functions of this camera. Chapters 4 onward explain the advanced functions, letting you learn more as you read each chapter.

Checking the Package Contents 2
Read This First 3
What Do You Want to Do? 4
Table of Contents 6
Conventions Used in This Guide 9
Safety Precautions.....10

1 Getting Started.....13

Compatible Memory Cards (Sold Separately) 14
Inserting the Batteries and Memory Card.....14
Setting the Date and Time 18
Setting the Display Language.....20
Formatting Memory Cards 21
Pressing the Shutter Button.....22
Taking Pictures (Smart Auto).....23
Viewing Images 26
Erasing Images.....27
Shooting or Viewing Images in Easy Mode.....28
Shooting Movies 29
Viewing Movies.....31
Transferring Images to a Computer for Viewing 32
Accessories 36
Separately Sold Accessories 37

2 Learning More 39

Components Guide.....40
Screen Display.....43
Indicators 44
FUNC. Menu – Basic Operations 45
MENU – Basic Operations.....46
Changing the Sound Settings 47
Adjusting the Screen Brightness 49
Returning the Camera to Default Settings 50
Power Saving Function (Auto Power Down)..... 51
Clock Functions..... 51

3 Shooting with Commonly Used Functions 53

Turning the Flash Off 54
Zooming in More Closely on Subjects (Digital Zoom) 55
Inserting the Date and Time..... 57
Using the Self-Timer 58
Changing the Recording Pixel Setting (Image Size)..... 61
Changing the Compression Ratio (Image Quality) 61

4 Adding Effects and Shooting in Various Conditions 63

Shooting in Various Conditions 64
Easily Changing the Brightness and Color When Shooting (Live View Control) 67
Shooting in Discreet Mode 68
Adding Effects and Shooting (Creative Filters) 68
Detecting a Face and Shooting (Smart Shutter) 73
Shooting Long Exposures 77

5 Choosing Settings Yourself 79

Shooting in Program AE 80
Adjusting the Brightness (Exposure Compensation) 81
Turning the Flash On 81
Adjusting the White Balance 82
Changing the ISO Speed 83
Correcting the Brightness and Shooting (i-Contrast) 84
Continuous Shooting 85
Changing the Tone of an Image (My Colors) 86
Shooting Close-ups (Macro) 87
Shooting Far Away Subjects (Infinity) 87
Changing the AF Frame Mode 88
Choosing the Subject to Focus On (Tracking AF) 90
Magnifying the Focal Point 91
Shooting with the AF Lock 92
Shooting with Servo AF 93
Choosing the Person to Focus On (Face Select) 94
Changing the Metering Method 95
Shooting with the AE Lock 96
Shooting with the FE Lock 96
Shooting with Slow Synchro 97
Red-Eye Correction 98
Checking for Shut Eyes 99
Shooting Using the Viewfinder 100
Shooting Using a TV as the Display 100

6 Using Various Functions for Shooting Movies 101

Changing the Movie Mode 102
Shoot Movies That Look Like a Miniature Model (Miniature Effect) 102
Changing the Image Quality 104
AE Lock/Exposure Shift 105
Other Shooting Functions 106
Editing 107

7 Using Various Playback and Editing Functions 109

Quickly Searching Images 110
Searching for Images Using the Jump Display 111
Viewing Slideshows 112
Checking the Focus 113
Magnifying Images 114
Displaying Various Images (Smart Shuffle) 114
Changing Image Transitions 115
Viewing Images on a TV 116
Protecting Images 117
Erasing All Images 120
Tagging Images as Favorites 122
Organizing Images by Category (My Category) 123
Rotating Images 125
Resizing Images 126
Trimming 127
Correcting the Brightness (i-Contrast) 129
Correcting the Red-Eye Effect 130

8 Printing 131

Printing Images 132
Choosing Images for Printing (DPOF) 139

9 Customizing Camera Settings 143


Changing Camera Settings 144
Changing Shooting Function Settings 151
Changing Playback Function Settings 154

10 Useful Information 155

Replacing the Date/Time Battery .. 156
Using Household Power 157
Troubleshooting 158
List of Messages That Appear on the Screen 161
Information Displayed on the Screen 163
Handling Precautions 167
Functions Available in Each Shooting Mode 168
Menus 172
Specifications 178
Index 181

Conventions Used in This Guide

- Icons are used in the text to represent the camera buttons and dials.
- Language that displays on the screen appears inside [ ] (square brackets).
- The directional buttons and FUNC./SET button are represented by the following icons.



- (!): Things you should be careful about
- : Troubleshooting tips
- : Hints for getting more out of your camera
- : Supplemental information
- (p. xx): Reference pages ("xx" stands for a page number)
- This guide assumes all functions are at their default settings.
- The various types of memory cards that can be used in this camera are collectively referred to as memory cards in this guide.

Safety Precautions

- Before using the product, please ensure that you read the safety precautions described below. Always ensure that the product is used correctly.
- The safety precautions noted on the following pages are intended to prevent injuries to yourself and other persons, or damage to the equipment.
- Be sure to also check the guides included with any separately sold accessories you use.

⚠ Warning Denotes the possibility of serious injury or death.

- **Do not trigger the flash in close proximity to people's eyes.**

Exposure to the intense light produced by the flash could damage eyesight. In particular, remain at least one meter (39 inches) away from infants when using the flash.

- **Store this equipment out of the reach of children and infants.**

Strap: Putting the strap around a child's neck could result in asphyxiation.
Time/date battery: Dangerous if swallowed. If this occurs, contact a doctor immediately.

- **Use only recommended power sources.**
- **Do not attempt to disassemble, alter or apply heat to the product.**
- **Avoid dropping or subjecting the product to severe impacts.**
- **To avoid the risk of injury, do not touch the interior of the product if it has been dropped or otherwise damaged.**
- **Stop using the product immediately if it emits smoke, a strange smell, or otherwise behaves abnormally.**
- **Do not use organic solvents such as alcohol, benzine, or thinner to clean the equipment.**
- **Do not let the product come into contact with water (e.g. sea water) or other liquids.**
- **Do not allow liquids or foreign objects to enter the camera.**

This could result in electrical shock or fire.
If liquids or foreign objects come into contact with the camera interior, immediately turn the camera power off and remove the batteries.

- **Do not use the camera's viewfinder in the presence of strong light sources (such as the sun on a clear day).**

This could damage your eyesight.

- **Use only the recommended batteries.**
- **Do not place the batteries near or in direct flame.**

The batteries may explode or leak, resulting in electrical shock or fire. This could cause injury and damage the surroundings. In the event that a battery leaks and the battery acid contacts eyes, mouth, skin or clothing, immediately flush with water.

- **Turn the camera off in places where camera use is prohibited.**

The electromagnetic waves emitted by the camera may interfere with the operation of electronic instruments and other devices. Exercise adequate caution when using the camera in places where use of electronic devices is restricted, such as inside airplanes and medical facilities.

- **Do not play the supplied CD-ROM(s) in any CD player that does not support data CD-ROMs.**

It is possible to suffer hearing loss from listening with headphones to the loud sounds of a CD-ROM played on a music CD player. Additionally, playing the CD-ROM(s) in an audio CD player (music player) could damage the speakers.

⚠ Caution Denotes the possibility of injury.

- **Be careful not to bang the camera or subject it to strong impacts or shocks when hanging it by the strap.**
- **Be careful not to bump or push strongly on the lens.**

This could lead to injury or damage the camera.

- **When using the flash, be careful not to cover it with your fingers or clothing.**

This could result in burns or damage to the flash.

- **Avoid using, placing or storing the product in the following places:**
  - **Places subject to strong sunlight**
  - **Places subject to temperatures above 40 °C (104 °F)**
  - **Humid or dusty areas**

These could cause leakage, overheating or an explosion of the batteries, resulting in electrical shock, fire, burns or other injuries.

- **The slideshow transition effects may cause discomfort when viewed for prolonged periods.**

Caution Denotes the possibility of damage to the equipment.

- **Do not aim the camera at bright light sources (such as the sun on a clear day).**

Doing so may damage the image sensor.

- **When using the camera on a beach or at a windy location, be careful not to allow dust or sand to enter the camera.**

This may cause the product to malfunction.

- **In regular use, small amounts of smoke may be emitted from the flash.**

This is due to the high intensity of the flash burning dust and foreign materials stuck to the front of the unit. Please use a cotton swab to remove dirt, dust or other foreign matter from the flash to prevent heat build-up and damage to the unit.

- **Remove and store the batteries when you are not using the camera.**

If the batteries are left inside the camera, damage caused by leakage may occur.

- **Before you discard the batteries, cover the terminals with tape or other insulators.**

Contacting other metal materials may lead to fire or explosions.

- **Do not charge batteries of different types at the same time, or use older batteries together with newer batteries.**
- **Do not insert the batteries with the + and – terminals reversed.**

This may cause the product to malfunction.

- **Do not sit down with the camera in your pocket.**

Doing so may cause malfunctions or damage the screen.

- **When putting the camera in your bag, ensure that hard objects do not come into contact with the screen.**
- **Do not attach any hard objects to the camera.**

Doing so may cause malfunctions or damage the screen.






1

Getting Started

This chapter explains preparations before shooting, how to shoot in AUTO mode, and then how to view and erase the images you take. The latter part of this chapter explains how to shoot and view images in Easy mode, how to shoot and view movies, and how to transfer images to a computer.

Attaching the Strap/Holding the Camera

- Attach the included strap and wrap it around your wrist to avoid dropping the camera during use.
- Keep your arms tight against your body while holding the camera firmly by the sides when shooting. Be sure that your fingers do not block the flash.



Compatible Memory Cards (Sold Separately)

The cards below can be used without restrictions on their capacities.


- SD memory cards*
- SDHC memory cards*
- SDXC memory cards*
- MultiMediaCards
- MMC*plus* memory cards
- HC MMC*plus* memory cards

* This memory card complies with the SD standards. Some cards may not operate properly depending on the brand of card used.

Depending on your computer's OS version, SDXC memory cards may not be recognized even when using a commercially available card reader. Check to make sure that your OS supports SDXC memory cards beforehand.


Inserting the Batteries and Memory Card

Insert the included batteries and a memory card (sold separately).




1 Check the card's write-protect tab.

- If the memory card has a write-protect tab, you will not be able to record images if the tab is in the locked position. Slide the tab up until you hear a click.




2 Open the cover.

- Slide and hold the cover lock (①), then slide and open the cover (②) as shown.




3 Insert the batteries.

- Insert the batteries with (+) and (-) ends oriented correctly.



4 Insert the memory card.

- Insert the memory card as shown until it locks into place with a click.
- Be sure the memory card is oriented correctly. Inserting the memory card in the wrong direction could damage the camera.




5 Close the cover.

- Close the cover (①), and press downward as you slide it until it clicks into place (②).

What if [Memory card locked] appears on the screen?

SD, SDHC and SDXC memory cards have a write-protect tab. If this tab is in the locked position, [Memory card locked] will appear on the screen and you will not be able to take or erase images.

Removing the Memory Card



- Push the memory card in until you hear a click, then slowly release it.
- ▶ The memory card will pop up.

Number of Possible Shots

Power Source		Alkaline Batteries (Supplied)	NiMH Batteries (Sold Separately)
Number of Shots	LCD Monitor On*	Approx. 200	Approx. 450
	LCD Monitor Off	Approx. 650	Approx. 1100
Playback Time		Approx. 8 hours	Approx. 11 hours

* The number of shots that can be taken is based on the Camera & Imaging Products Association (CIPA) measurement standard.
- Under some shooting conditions, the number of shots that can be taken may be less than mentioned above.
- Depending on the brand of alkaline batteries used, the number of shots that can be taken may vary widely.
- The values for NiMH batteries are based on fully charged batteries.

Compatible Batteries

AA alkaline batteries and Canon AA NiMH batteries (sold separately) (p. 37).

Can any other batteries be used?

We cannot recommend the use of any other batteries than those listed above because performance varies widely.

Why use NiMH batteries?

NiMH batteries last much longer than alkaline batteries, especially in cold weather.

Battery Charge Indicator

When battery charge is low, an icon and message will appear. If the batteries are charged, the icon and message will not appear.

Display	Summary
	Nearly depleted. Ready new batteries.
“Change the batteries”	Depleted. Change the batteries.

Number of Shots per Memory Card


Memory Card	4 GB	16 GB
Number of Shots	Approx. 1231	Approx. 5042

- Values are based on the default settings.
- The number of shots that can be taken will vary depending on camera settings, the subject and the memory card used.

Can you check the number of shots that can be taken?


You can check the number of shots that can be taken when the camera is in a Shooting mode (p. 23).

Number of shots that can be taken




Setting the Date and Time

The Date/Time settings screen will appear the first time the camera is turned on. Since the dates and times recorded into your images are based on these settings, be sure to set them.



1 Turn on the camera.

- Press the ON/OFF button.
- ▶ The Date/Time screen will appear.



2 Set the date and time.

- Press the ◀▶ buttons to choose an option.
- Press the ▲▼ buttons to set a value.





3 Complete the setting.

- Press the (FUNC SET) button.
- ▶ Once the date and time have been set, the Date/Time screen will close.
- Pressing the ON/OFF button will turn off the camera.

Reappearing Date/Time screen


Set the correct date and time. If you have not set the date and time, the Date/Time screen will appear each time you turn on the camera.

Daylight saving time settings

If you choose ☀OFF in Step 2 and press the ▲▼ buttons to choose ☀, you will set the time to daylight saving (1 hour ahead).


Changing the Date and Time

You can change the current date and time settings.



1 Display the menu.


- Press the MENU button.



2 Choose [Date/Time] from the tab.

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Date/Time], then press the (FUNC. SET) button.





3 Change the date and time.


- Follow Steps 2 and 3 on p. 18 to adjust the setting.
- Press the MENU button to close the menu.

Date/Time battery

If the Date/Time screen appears even when the date/time have been correctly set, insert a new date/time battery (p. 156).


Setting the Display Language

You can change the language that displays on the screen.



1 Enter Playback mode.

- Press the ▶ button.



2 Display the settings screen.

- Press and hold the (FUNC. SET) button, then immediately press the MENU button.



3 Set the display language.

- Press the ▲▼◀▶ buttons to choose a language, then press the (FUNC. SET) button.
- Once the display language has been set, the settings screen will close.




What if the clock appears when the (FUNC. SET) button is pressed?

The clock will appear if too much time passes between pressing the (FUNC. SET) button and the MENU button in Step 2. If the clock appears, press the (FUNC. SET) button to remove the clock and repeat Step 2.

You can also change the display language by pressing the MENU button to choose [Language] from the 🔧 tab.

Formatting Memory Cards

Before you use a new memory card or one that has been formatted in other devices, you should format the card with this camera.
Formatting (initializing) a memory card erases all data on the memory card. As you cannot retrieve the erased data, exercise adequate caution before formatting the memory card.



1 Display the menu.


- Press the MENU button.






2 Choose [Format].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Format], then press the (FUNC SET) button.



3 Choose [OK].

- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.



4 Format the memory card.

- Press the ▲▼ buttons to choose [OK], then press the (FUNC SET) button.
- ▶ The memory card will be formatted.

5 Complete formatting.


- When formatting ends, [Memory card formatting complete] will appear on the screen.
- Press the (FUNC SET) button.

Formatting or erasing data on a memory card merely changes the file management information on the card and does not ensure its contents are completely erased. Be careful when transferring or disposing of a memory card. When disposing of a memory card, take precautions such as physically destroying the card to prevent personal information leaks.

- The total capacity of the memory card displayed in the formatting screen may be less than indicated on the memory card.
- Perform a low-level format (p. 145) of the memory card when the camera does not operate properly, the recording/reading speed of a memory card has dropped, when continuous shooting speed slows down, or when movie recording stops suddenly.


Pressing the Shutter Button

To take images that are in focus, be sure to first press the shutter button lightly (halfway) to focus, then press fully to shoot.



1 Press halfway (Press lightly to focus).

- Press lightly until the camera beeps twice and AF frames appear where the camera focused.



2 Press fully (Press fully to shoot).

- The camera plays the shutter sound and takes the shot.

If you shoot without pressing the shutter button halfway, the image may not be in focus.


Taking Pictures (Smart Auto)

Since the camera can determine the subject and shooting conditions, you can let it automatically select the best settings for the scene and just shoot. The camera can also detect and focus on faces, setting the color and brightness to optimal levels.



1 Turn on the camera.


- Press the ON/OFF button.
- ▶ The start-up screen will appear.






2 Enter AUTO mode.

- Set the mode dial to AUTO.
- When you point the camera toward the subject, the camera will make a slight noise as it determines the scene.
- ▶ The icon for the determined scene will appear in the upper right of the screen.
- ▶ The camera will focus on detected subjects and display frames on them.



3 Compose the shot.

- Moving the zoom lever toward [telephoto] (telephoto) will zoom in on your subject, making it appear larger. Moving the lever toward [wide angle] (wide angle) will zoom out from your subject, making it appear smaller. (The zoom bar showing the zoom position appears on the screen.)




4 Focus.

- Press the shutter button halfway to focus.



AF Frame

▶ When the camera focuses, it will beep twice and AF frames will appear where the camera focused.
Several AF frames will appear when the camera focuses on more than one point.



5 Shoot.

- Press the shutter button fully to shoot.
- ▶ The camera will play the shutter sound and shoot. The flash will automatically fire in low light conditions.
- ▶ The image will appear on the screen for approximately two seconds.
- You can take a second picture even while an image is displayed by pressing the shutter button again.

What if...

- **What if the color and brightness of the images do not turn out as expected?**
  The scene icon (p. 164) that appears on the screen may not match the actual scene. If this happens, try shooting in **P** mode (p. 79).
- **What if the screen is off even when the camera is turned on?**
  Press the DISP. button to turn on the screen.
- **What if white and gray frames appear when you point the camera toward a subject?**
  A white frame appears on the face or subject that the camera detected as the main subject, while gray frames appear on other detected faces. The frames will follow the subjects within a certain range (p. 88).
  If the subject moves, however, the gray frames will disappear, leaving only the white frame.
- **What if a frame does not appear on the subject you want to shoot?**
  The subject may not be detected, and frames may appear on the background. If this happens, try shooting in **P** mode (p. 79).

- **What if a blue frame appears when you press the shutter button halfway?**
  A blue frame appears when a moving subject is detected; the focus and exposure will continuously adjust (Servo AF).
- **What if a flashing appears?**
  Attach the camera to a tripod so that the camera does not move and blur the image.
- **What if the camera does not play any sounds?**
  Pressing the DISP. button while turning on the camera power will turn off all sounds. To turn the sounds on, press the MENU button to choose [Mute] from the tab, then press the ◀▶ buttons to choose [Off].
- **What if the image comes out dark even if the flash fired when shooting?**
  The subject is too far away for the flash to reach. The effective flash range is approximately 30 cm – 4.0 m (12 in. – 13 ft.) at maximum wide angle (), and approximately 50 cm – 2.0 m (1.6 – 6.6 ft.) at maximum telephoto ().
- **What if the camera beeps once when the shutter button is pressed halfway?**
  Your subject may be too close. When the camera is at maximum wide angle (), move about 3 cm (1.2 in.) or more away from your subject and shoot. Move about 80 cm (2.6 ft.) or more away when the camera is at maximum telephoto ().
- **What if the lamp lights when the shutter button is pressed halfway?**
  To reduce red-eye and to assist in focusing, the lamp may light when shooting in dark areas.
- **What if the screen turns off when you try to shoot?**
  When flash recharging begins, the screen turns off. The screen turns on again when recharging ends.

What if an icon appears in the upper right of the screen?


The icon for the determined scene will appear in the upper right of the screen. For details on the icons that appear, see “Scene Icons” (p. 164).

Choosing the subject to focus on (Tracking AF)

After pressing the ▲ button and displaying , point the camera so that is on the subject you want to focus on. Press and hold the shutter button halfway to display a blue frame where focus and exposure will be maintained (Servo AF). Press the shutter button fully to shoot.

Viewing Images

You can view the images you have taken on the screen.



1 Enter Playback mode.

- Press the [▶] button.
- ▶ The last image you took will appear.



2 Choose an image.


- Pressing the ◀ button will cycle through the images from newest to oldest.
- Pressing the ▶ button will cycle through the images from oldest to newest.
- Pressing and holding the ◀▶ buttons will display images in a line letting you quickly search them. Pressing the (FUNC/SET) button restores single image playback (p. 110).
- The lens will retract after approximately 1 minute elapses.
- Pressing the [▶] button again while the lens is retracted will turn off the power.

Switching to Shooting mode

Pressing the shutter button halfway, or turning the mode dial in Playback mode switches the camera to Shooting mode.

Erasing Images

You can choose and erase images one at a time. Please note that erased images cannot be recovered. Exercise adequate caution before erasing an image.



1 Enter Playback mode.

- Press the [▶] button.
- ▶ The last image you took will appear.



2 Choose an image to erase.

- Press the ◀▶ buttons to display an image to erase.





3 Erase the image.


- Press the ▼ button.
- ▶ [Erase?] appears on the screen.
- Press the ◀▶ buttons to choose [Erase], then press the (FUNC SET) button.
- ▶ The displayed image will be erased.
- To exit instead of erasing, press the ◀▶ buttons to choose [Cancel], then press the (FUNC SET) button.




Shooting or Viewing Images in Easy Mode

In Easy mode, operational instructions are displayed on the screen, and the camera is set so that only the buttons and the zoom lever explained on this page are functional. This prevents incorrect operation of the camera, allowing even beginners to take worry-free pictures.


Shooting





- Set the mode dial to 📷.
- Follow Steps 3 – 5 on pp. 23 – 24 to shoot (no sound will play).
- Press the ▶ button to turn off the flash. ⚡ will appear on the screen. Pressing the ▶ button again turns on the flash and ⚡A appears on the screen. The flash will automatically fire in low light conditions.


Viewing



- Press the ▶ button, then press the ◀▶ buttons to switch images.
- Press the ▶ button, then press the FUNC SET button, and all the shots you have taken will display for about 3 seconds each. Press the FUNC SET button again to stop the slideshow.
- To erase images, follow the steps on p. 27.

Shooting Movies

The camera can automatically select all settings so that you can shoot movies just by pressing the shutter button.



Remaining Time




1 Enter mode.

- Set the mode dial to .




2 Compose the shot.

- Moving the zoom lever toward [] will zoom in on your subject, making it appear larger. Moving the lever toward [] will zoom out from your subject, making it appear smaller.




3 Focus.

- Press the shutter button halfway to focus.
- ▶ When the camera focuses, it will beep twice.




4 Shoot.

- Press the shutter button fully.



- ▶ Recording will start, and [●Rec] and the elapsed time will appear on the screen.
- Once shooting begins, take your finger off the shutter button.
- If you change the composition of your shot during shooting, the focus will stay the same, but the brightness and tone will automatically adjust.



- Do not touch the microphone while shooting.
- Do not press any buttons other than the shutter button while shooting. The sound the buttons make will be recorded in the movie.



5 Stop shooting.

- Press the shutter button fully again.
- ▶ The camera will beep once and stop shooting the movie.
- ▶ The movie will record to the memory card.
- ▶ Shooting will automatically stop when the memory card fills.

Zooming while shooting

Pressing the zoom lever while shooting will zoom in on or out from the subject. However, movies shot at zoom factors that appear in blue will be coarse. Operation sounds will be recorded.


Shooting Time

Memory Card	4 GB	16 GB
Shooting Time	Approx. 26 min. 48 sec.	Approx. 1 hr. 49 min. 48 sec.

- Shooting times are based on default settings.
- Maximum clip length is approx. 10 minutes.
- Recording may stop even if the maximum clip length has not been reached on some memory cards. SD Speed Class 4 or higher memory cards are recommended.

Viewing Movies

You can view the movies you have shot on the screen.



1 Enter Playback mode.

- Press the ▶ button.
- ▶ The last image you took will appear.
- ▶ SET appears on movies.





2 Choose a movie.

- Press the ◀▶ buttons to choose a movie, then press the (FUNC SET) button.
- The movie control panel will appear.





3 Play the movie.

- Press the ◀▶ buttons to choose ▶ (Play), then press the (FUNC SET) button.
- ▶ The movie will play.
- If you press the (FUNC SET) button, you can pause or resume playback.
- Press the ▲▼ buttons to adjust the volume.
- ▶ After the movie finishes, SET appears.

How can I play back movies on a computer?

Install the included software (p. 33).

- When watching a movie on a computer, frames may drop, it may not play smoothly, and the audio may stop suddenly depending on the computer's capabilities.
- If you use the supplied software to copy the movie back onto the memory card, you can play back the movie smoothly with the camera. For enhanced playback you can also connect the camera to a TV.

Transferring Images to a Computer for Viewing

You can use the included software to transfer images you have shot with the camera to a computer for viewing. If you are already using software included with another Canon-brand compact digital camera, install the software from the included CD-ROM, overwriting your current installation.

System Requirements

Windows

OS	Windows 7 Windows Vista Service Pack 1 and 2 Windows XP Service Pack 3
Computer model	The above OS should be pre-installed on computers with built-in USB ports.
CPU	Pentium 1.3 GHz or higher (still images), Core2 Duo 1.66 GHz or higher (movies)
RAM	Windows 7 (64 bit): 2 GB or more Windows 7 (32 bit), Windows Vista (64 bit, 32 bit): 1 GB or more Windows XP: 512 MB or more (still images), 1 GB or more (movies)
Interface	USB
Free Hard Disk Space	ZoomBrowser EX: 200 MB or more CameraWindow: 150 MB or more* Movie Uploader for YouTube: 30 MB or more PhotoStitch: 40 MB or more
Display	1,024 x 768 pixels or higher

* For Windows XP, Microsoft .NET Framework 3.0 or later (max. 500 MB) must be installed. Installation may take some time depending on your computer's capabilities.

Macintosh

OS	Mac OS X (v10.5 – v10.6)
Computer model	The above OS should be pre-installed on computers with built-in USB ports.
CPU	Intel Processor (still images), Core Duo 1.66 GHz or higher (movies)
RAM	Mac OS X v10.6: 1 GB or more Mac OS X v10.5: 512 MB or more (still images), 1 GB or more (movies)
Interface	USB
Free Hard Disk Space	ImageBrowser: 250 MB or more CameraWindow: 150 MB or more Movie Uploader for YouTube: 30 MB or more PhotoStitch: 50 MB or more
Display	1,024 x 768 pixels or higher

Preparations

Windows Vista and Mac OS X (v10.5) are used for these explanations.

1 Install the Software.



Windows


① Place the CD in the computer's CD-ROM drive.

- Place the supplied CD-ROM (DIGITAL CAMERA Solution Disk) (p. 2) into the computer's CD-ROM drive.



② Begin installation.

- Click [Easy Installation] and follow the on-screen instructions to proceed with the installation.
- If the [User Account Control] window appears, follow the on-screen instructions to proceed.



③ When the installation finishes, click [Restart] or [Finish].

④ Remove the CD-ROM.

- Remove the CD-ROM when your desktop screen appears.

Macintosh


① Place the CD in the computer's CD-ROM drive.


- Place the supplied CD-ROM (DIGITAL CAMERA Solution Disk) (p. 2) into the computer's CD-ROM drive.



② Begin installation.


- Double-click the  on the CD.
- Click [Install], and follow the on-screen instructions to proceed with the installation.





2 Connect the camera to the computer.

- Turn off the camera.
- Open the cover and insert the included interface cable's smaller plug (p. 2) firmly into the camera terminal in the direction shown.
- Insert the interface cable's larger plug into the computer. For connection details, refer to the user guide provided with the computer.



3 Turn on the camera.

- Press the ▶ button to turn on the camera.

4 Open CameraWindow.



Windows

- Click [Downloads Images From Canon Camera using Canon CameraWindow].
- ▶ CameraWindow will appear.
- If CameraWindow does not appear, click the [Start] menu and choose [All Programs], followed by [Canon Utilities], [CameraWindow] and [CameraWindow].



Macintosh

- ▶ CameraWindow will appear when you establish a connection between the camera and computer.
- If CameraWindow does not appear, click the CameraWindow icon on the Dock (the bar which appears at the bottom of the desktop).

For Windows 7, use the following steps to display CameraWindow.
① Click on the task bar.
② In the screen that appears, click the link to modify the program.
③ Choose [Downloads Images From Canon Camera using Canon CameraWindow] and click [OK].
④ Double click .


Transfer and View Images



- Click [Import Images from Camera], and then click [Import Untransferred Images].
- ▶ All images not previously transferred will transfer to the computer. Transferred images will be sorted by date and saved in separate folders in the Pictures folder.
- Close CameraWindow when image transfer is complete.
- Turn off the camera and unplug the cable.
- For details on how to view images using a computer, refer to the *Software Guide*.

You can transfer images even without using the image transfer function in the included software by simply connecting your camera to a computer. There are, however, the following limitations.
- It may take a few minutes from when you connect the camera to the computer until you can transfer images.
- Images shot in the vertical orientation may be transferred in the horizontal orientation.
- Protection settings for images may be lost when transferred to a computer.
- There may be problems transferring images or image information correctly depending on the version of the operating system in use, the file size, or the software in use.
- Some functions in the included software may not be available, such as editing movies, and transferring images to the camera.


Accessories



Separately Sold Accessories


The following camera accessories are sold separately. Some accessories are not sold in some regions, or may no longer be available.

Power Supplies



AC Adapter Kit ACK800

- This kit lets you power the camera using household power. Recommended for powering the camera for an extended period of time or when connecting to a computer or printer. Cannot be used to charge the camera batteries.



Battery and Charger Kit CBK4-300

- This dedicated battery charger kit includes both Battery Charger CB-5AH and four NB-3AH rechargeable AA NiMH (nickel metal hydride) batteries. Recommended for powering the camera for an extended period of time.

You can also purchase NiMH Battery NB4-300, a set of four rechargeable AA NiMH batteries separately. Battery and Charger Kit CBK4-200 can also be used.

Using Accessories Abroad

The battery charger and the AC adapter kit can be used in regions that have 100 – 240 V (50/60 Hz) AC power.
If the plug does not fit the outlet, use a commercially available plug adapter.
Do not use electrical transformers for foreign travel as they will cause damage.

Flash



High-Power Flash HF-DC1

- This externally mounted flash can be used to capture photographic subjects that are too distant for the built-in flash to illuminate.

Other Accessories



AV Cable AVC-DC300

- Use this cable to connect to a TV for shooting and viewing images.

Printers



SELPHY series



Inkjet Printers

Canon-Brand PictBridge Compliant Printers

- By connecting your camera to a Canon-brand PictBridge compliant printer, you can print your images without having to use a computer.
  For more information, visit your nearest Canon retailer.

Use of genuine Canon accessories is recommended.

This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.


2

Learning More

This chapter explains the parts of the camera and what appears on the screen, as well as the basic operating instructions.




Components Guide



① Viewfinder
② Microphone (p. 30)
③ Lens
④ Mode Dial
⑤ Zoom Lever
Shooting: (Telephoto) / (Wide Angle) (pp. 23, 29, 55)
Playback: (Magnify) / (Index) (pp. 110, 114)
⑥ Shutter Button (p. 22)
⑦ ON/OFF Button (p. 18)
⑧ Lamp (pp. 59, 60, 76, 151)
⑨ Flash (pp. 54, 81, 97)
⑩ DIGITAL Terminal (pp. 34, 132)
⑪ A/V OUT (Audio/Video Output) Terminal (p. 116)
⑫ DC IN (Power Input) Terminal (p. 157)
⑬ Tripod Socket
⑭ Cover Lock (p. 14)
⑮ Memory Card / Battery Cover (p. 14)
⑯ Strap Mount (p. 13)

Mode Dial

Use the mode dial to change the Shooting mode.



P Mode
Choose settings yourself to take various types of pictures (p. 80).

Live View Control Mode
The brightness and color can be easily set to your preferences for shooting (p. 67).

Auto Mode
You can leave it to the camera to select settings for fully automatic shooting (p. 23).

Easy Mode
You can shoot just by pressing the shutter button (p. 28).


Special Scene Mode
You can shoot with the optimum settings for the scene (p. 64).

Movie Mode
For shooting movies (pp. 29, 101).
You can use the largest possible portion of the screen to shoot movies (p. 104).

Discreet Mode
You can shoot with the flash disabled and all camera sounds muted (p. 68).

Creative Filters Mode
You can add various effects to images when shooting (p. 68).

If you turn the mode dial while in Playback mode, the camera will switch to Shooting mode.




① Screen (LCD Monitor) (pp. 43, 163, 165)
② Speaker
③ Viewfinder
④ Indicators (p. 44)
⑤ (Face Selector) Button (p. 94)
⑥ (Playback) Button (pp. 26, 109)
⑦ DISP. (Display) Button (p. 43)
⑧ MENU Button (p. 46)
⑨ (Exposure Compensation) (p. 81) / (Jump) (p. 111) / ▲ Button
⑩ (Macro) (p. 87) / ◀ Button
⑪ FUNC./SET Button (p. 45)
⑫ (Flash) (pp. 54, 81, 97) / ▶ Button
⑬ (Self-Timer) (pp. 58, 59, 60) / (Single Image Erase) (p. 27) / ▼ Button

Screen Display


Switching the Display

You can change the screen display using the DISP. button. Refer to p. 163 for details on information that appears on the screen.

Shooting



Playback



You can also switch the display by pressing the DISP. button while the image displays right after shooting. However, Simple Information Display is not available. You can change the display that appears first by pressing the MENU button, then choosing [Review info] from the tab (p. 152).


Screen Display in Dark Shooting Conditions

The display automatically brightens when shooting in dark conditions, allowing you to check the composition (Night Display function). However, the brightness of the image on the screen, and the brightness of the actual image recorded may be different. Screen noise may appear and the movement of the subject may appear somewhat jagged on the screen. This has no effect on the recorded image.

Overexposure Warning during Playback

In Detailed Information Display (p. 43), overexposed areas of the image flash on the screen.

Histogram during Playback



- The graph that appears in Detailed Information Display (p. 165) is called the histogram. The histogram shows the distribution of brightness in an image horizontally, and the amount of brightness vertically. When the graph approaches the right side, the image is bright, but when it approaches the left side, the image is dark, and in this way you can judge the exposure.

Indicators

The indicators on the back of the camera (p. 42) will light or blink depending on the camera's status.

Colors	Status	Operation Status
Green	Lights	Camera ready, display off (p. 149)
	Blinks	During camera start-up, recording/reading/transmitting image data, proximity warning (p. 25), cannot focus (flash will not fire) (p. 159)
Orange	Lights	Camera ready (flash will fire)
	Blinks	Proximity warning (p. 25), cannot focus (flash will fire) (p. 159)

When the indicator blinks green, do not turn off the power, open the memory card slot/battery cover, shake or jolt the camera. These actions may corrupt the image data or cause the camera or memory card to malfunction.

FUNC. Menu – Basic Operations

You can set commonly used shooting functions using the FUNC. menu. The menu items and options differ depending on the Shooting mode (pp. 168 – 171).



1 Display the FUNC. menu.

- Press the (FUNC SET) button.



2 Choose a menu item.

- Press the ▲▼ buttons to choose a menu item.
- ▶ The available options for the menu item appear in the lower part of the screen.
- Choosing some menu items changes the screen to display further menu options.

3 Choose an option.

- Press the ◀▶ buttons to choose an option.
- You can also choose settings by pressing the DISP. button on options that display (DISP.).






4 Complete the setting.

- Press the (FUNC SET) button.
- ▶ The shooting screen will reappear and the setting you chose will display on the screen.

MENU – Basic Operations

Various functions can be set from the menus. The menu items are organized under tabs, such as for shooting (📷) and playback (▶). The options differ depending on the Shooting mode and the Playback mode (pp. 172 – 177).



1 Display the menu.

- Press the MENU button.



2 Choose a tab.

- Move the zoom lever or press the ◀▶ buttons to choose a tab.

3 Choose an item.

- Press the ▲▼ buttons to choose an item.
- Some items require you to press the (FUNC SET) or ▶ button to display a submenu in which you change the setting.






4 Choose an option.

- Press the ◀▶ buttons to choose an option.

5 Complete the setting.


- Press the MENU button to restore the normal screen.



Changing the Sound Settings

You can silence or adjust the volume of camera sounds.

Muting Sounds



1 Display the menu.

- Press the MENU button.




2 Choose [Mute].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Mute], then press the ◀▶ buttons to choose [On].
- Press the MENU button to restore the normal screen.



- You cannot change the sound settings in .
- You can also mute camera sounds by holding down the DISP. button and turning on the power.
- If you mute camera sounds, the sound will also be muted when playing back movies (p. 31). If you press the ▲ button while playing back a movie, the sound will play back, and you can adjust the volume with the ▲▼ buttons.

Adjusting the Volume



1 Display the menu.

- Press the MENU button.



2 Choose [Volume].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Volume], then press the (FUNC SET) button.






3 Change the volume.

- Press the ▲▼ buttons to choose an item, then press the ◀▶ buttons to adjust the volume.
- Press the MENU button twice to restore the normal screen.

Adjusting the Screen Brightness

You can adjust the brightness of the screen.



1 Display the menu.

- Press the MENU button.



2 Choose [LCD Brightness].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [LCD Brightness].


3 Adjust the brightness.

- Press the ◀▶ buttons to adjust the brightness.
- Press the MENU button twice to restore the normal screen.



Returning the Camera to Default Settings

When you have mistakenly changed a setting, you can reset the camera to the default settings.



1 Display the menu.

- Press the MENU button.



2 Choose [Reset All].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Reset All], then press the (FUNC SET) button.





3 Reset the settings.

- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.
- ▶ The camera will reset to the default settings.

Are there functions that cannot be reset?

- The [Date/Time] (p. 19), [Language] (p. 20), [Video System] (p. 116), [Time Zone] (p. 149), and the image registered in [Start-up Image] (p. 146) in the tab.
- The recorded custom white balance data (p. 82).
- The shooting mode chosen in SCN (p. 64) or (p. 68).
- The Movie mode (p. 29).

Power Saving Function (Auto Power Down)

To save battery power, the screen turns off, and the camera shuts down automatically when it is not operated for a certain time.

Power Saving during Shooting

The screen will turn off approximately 1 minute after you stop operating the camera. After about 2 more minutes, the lens will retract and the power will turn off. When the screen has turned off but the lens has not yet retracted, pressing the shutter button halfway (p. 22) turns on the screen and shooting can continue.


Power Saving during Playback

The power will turn off approximately 5 minutes after you stop operating the camera.

- You can turn off the power saving function (p. 148).
- You can adjust the time before the screen turns off (p. 149).

Clock Functions

You can check the current time.






- Press and hold the (FUNC SET) button.
- ▶ The current time appears.
- If you hold the camera vertically while using the clock function, it will switch to vertical display. Press the ◀▶ buttons to change the display color.
- Press the (FUNC SET) button again to cancel the clock display.

When the camera power is off, press and hold the (FUNC SET) button, then press the ON/OFF button to display the clock.

3

Shooting with Commonly Used Functions

This chapter explains how to use common functions, such as the self-timer, and how to turn off the flash.



- This chapter assumes that the camera is set to AUTO mode. When shooting in another mode, check which functions are available in that mode (pp. 168 – 171).

Turning the Flash Off

You can shoot with the flash turned off.



1 Press the ▶ button.



2 Choose ⊗.

- Press the ◀▶ buttons to choose ⊗, then press the (FUNC SET) button.
- ▶ Once set, ⊗ will appear on the screen.
- To turn the flash back on, follow the steps above to choose ϟ^{A}.




What if a flashing appears?

When you press the shutter button halfway in low light conditions where camera shake is likely, a flashing will appear on the screen. Attach the camera to a tripod to prevent it from moving.


Zooming in More Closely on Subjects (Digital Zoom)

You can use the digital zoom to zoom up to approximately 16x maximum, and capture subjects that are too far away for the optical zoom to enlarge. However, depending on the recording pixel setting (p. 61) and zoom factor, the images may appear coarse (the zoom factor will appear in blue).



1 Move the zoom lever toward [🔺].

- Hold the lever until zooming stops.
- ▶ Zooming stops at the largest possible zoom factor without image deterioration. The zoom factor will appear on the screen when you release the zoom lever.



2 Move it toward [🔺] again.

- ▶ The digital zoom will zoom in even further on the subject.


Turning off the digital zoom

To turn off the digital zoom, press the MENU button to choose [Digital Zoom] from the 📷 tab, then choose [Off].

The focal length when using the optical zoom and digital zoom together is approximately 28 – 448 mm, and 28 – 112 mm when using the optical zoom alone (all focal lengths are 35mm film equivalent).

Digital Tele-Converter

The focal length of the lens can be increased by approximately 1.5x or approximately 2.0x. This enables a faster shutter speed and less chance of camera shake than the zoom (including digital zoom) used by itself at the same zoom factor.
However, a recording pixel setting (p. 61) of L or M1 will cause images to appear coarse (the zoom factor will appear in blue).



1 Display the menu.

- Press the MENU button.



2 Choose [Digital Zoom].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Digital Zoom].




3 Choose the setting.

- Press the ◀▶ buttons to choose a magnification.
- Press the MENU button to complete the setting and restore the shooting screen.
- ▶ The view will be enlarged and the zoom factor will appear on the screen.
- To return to standard digital zoom, choose [Digital Zoom] and the [Standard] option.

- The respective focal lengths when using [1.5x] and [2.0x] are approximately 42.0 – 168 mm and approximately 56.0 – 224 mm (35mm film equivalent).
- The digital tele-converter cannot be used together with the digital zoom.
- The shutter speeds may be the same when at maximum telephoto ([ ]), and when zoomed in on the subject using Step 2 on p. 55.


Inserting the Date and Time

You can insert the shooting date and time in the lower right corner of an image. Once inserted, however, they cannot be deleted. Be sure to check beforehand that the date and time are correctly set (p. 18).



1 Display the menu.

- Press the MENU button.





2 Choose [Date Stamp].

- Move the zoom lever to choose the tab.
- Press the ▲▼ buttons to choose [Date Stamp].

3 Choose the setting.

- Press the ◀▶ buttons to choose [Date] or [Date & Time].
- Press the MENU button to complete the setting and restore the shooting screen.

▶ Once set, [DATE] will appear on the screen.



4 Shoot.

▶ The shooting date or time will be recorded in the image's lower right corner.

- To restore to the original setting, choose [Off] in Step 3.

You can insert and print the shooting date in images which do not have an embedded date and time as follows. However, if you do this for images with an embedded date and time, the date and time may be printed twice.

- **Use the DPOF print settings (p. 139) to print.**
- **Use the included software to print.**
  Refer to the *Software Guide* for details.
- **Print using printer functions (p. 134).**

Using the Self-Timer

The self-timer can be used to shoot a group photo that includes the photographer. The camera will shoot approximately 10 seconds after the shutter button is pressed.




1 Press the ▼ button.




2 Choose ⏲10.

- Press the ▲▼ buttons to choose ⏲10, then press the (FUNC. SET) button.
- ▶ Once set, ⏲10 will appear on the screen.







3 Shoot.

- Press the shutter button halfway to focus on the subject, then press it fully.
- ▶ When the self-timer starts, the lamp blinks and the self-timer sound plays.
- ▶ Two seconds before the shutter releases, the lamp and sound speed up (the lamp remains lit when the flash will fire).
- To cancel shooting with the self-timer after the countdown has started, press the ▼ button.
- To restore the original setting, choose OFF in Step 2.

You can change the delay and number of shots (p. 60).

Using the Self-Timer to Prevent Camera Shake

The camera will shoot approximately 2 seconds after the shutter button is pressed, preventing any camera shake that occurs when pressing the shutter button.



Choose 2.

- Follow Step 2 on p. 58 to choose 2.
- ▶ Once set, 2 will appear on the screen.
- Follow Step 3 above to shoot.

Customizing the Self-Timer

You can set the delay (0 – 30 seconds) and the number of shots (1 – 10 shots).



1 Choose ⏲.

- Follow Step 2 on p. 58 to choose ⏲, then press the MENU button immediately.



2 Choose the settings.

- Press the ▲▼ buttons to choose [Delay] or [Shots].
- Press the ◀▶ buttons to choose a value, then press the (FUNC SET) button.
- ▶ Once set, ⏲ will appear on the screen.
- Follow Step 3 on p. 59 to shoot.

What if the number of shots is set to two or more shots?

- Exposure and white balance settings are set with the first shot.
- If the flash fires or you set a high number of shots, the shooting interval may take longer than usual.
- If the memory card fills, shooting stops automatically.

When you set the delay for more than 2 seconds, the lamp and self-timer sound speed up 2 seconds before the shutter releases (the lamp remains lit when the flash will fire).

Changing the Recording Pixel Setting (Image Size)

You can choose from 5 recording pixel settings.





1 Choose the recording pixel setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose L.


2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.
- To restore the original setting, choose L in Steps 1 – 2.

If you choose W, you cannot use the digital zoom (p. 55) or digital tele-converter (p. 56).

Changing the Compression Ratio (Image Quality)

You can choose from the following 2 compression ratios (image quality): ◢ (Fine), ◢ (Normal).





1 Choose the compression ratio setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose ◢.

2 Choose an option.


- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.
- To restore the original setting, choose ◢ in Steps 1 – 2.

Approximate Values for Recording Pixels and Compression Ratio

Recording Pixels	Compression Ratio	Single Image Data Size (Approx. KB)	Number of Shots per Memory Card (Approx. shots)	
			4 GB	16 GB
L (Large) 12M/4000x3000	◢	3084	1231	5042
	▟	1474	2514	10295
M1 (Medium 1) 6M/2816x2112	◢	1620	2320	9503
	▟	780	4641	19007
M2 (Medium 2) 2M/1600x1200	◢	558	6352	26010
	▟	278	12069	49420
S (Small) 0.3M/640x480	◢	150	20116	82367
	▟	84	30174	123550
W (Widescreen) 4000x2248	◢	2311	1630	6677
	▟	1105	3352	13727

- The values in the table are measured according to Canon standards and may change depending on the subject, memory card and camera settings.

Approximate Values for Paper Size




- S For sending images as e-mail attachments.
- W For displaying on wide-screen HD TVs with an aspect ratio of 16:9.

4


Adding Effects and Shooting in Various Conditions

This chapter explains how to add effects and how to shoot in various conditions.



Shooting in Various Conditions

The camera will select the necessary settings for the conditions in which you wish to shoot when you choose the matching mode.



1 Enter SCN mode.

- Set the mode dial to **SCN**.



2 Choose a Shooting mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose (🚶).
- Press the ◀▶ buttons to choose a Shooting mode, then press the (FUNC SET) button.



3 Shoot.



(🚶) Take shots with reduced blur (Blur Reduction)

- Lets you shoot with reduced camera shake and subject blur.



Take portraits (Portrait)

- Produces a soft effect when photographing people.



Take landscapes (Landscape)

- Lets you shoot majestic landscapes with a real sense of depth.



Take shots of kids and pets (Kids&Pets)

- Lets you capture subjects that move around, such as children and pets, without missing photo opportunities.
- Move approximately 1 m (3.3 ft.) or more away from your subject and shoot.



Take shots in low light conditions (Low Light)

- Lets you take shots in dark places with reduced camera shake and subject blur.



Take shots of people at the beach (Beach)

- Lets you take shots of brightly lit people on sandy beaches where the reflected sunlight is strong.



Take shots of foliage (Foliage)

- Lets you shoot trees and leaves, such as new growth, autumn leaves or blossoms, in vivid colors.



Take shots of people in snow (Snow)

- Lets you take bright, natural-colored shots of people against snowy backgrounds.



Take shots of fireworks (Fireworks)

- Lets you take shots of fireworks in vivid colors.


In mode, attach the camera to a tripod to prevent the camera from moving and blurring the image.

- In and modes, the recording pixel setting will be fixed at M (1600 x 1200 pixels).
- In mode, images may appear coarse because the ISO speed (p. 83) is increased to match the shooting conditions.

Easily Changing the Brightness and Color When Shooting (Live View Control)

You can easily change the brightness, color and tone to match your preferences when shooting.





1 Set the camera to LIVE mode.

- Set the mode dial to LIVE.

2 Press the (FUNC SET) button.

- The setting screen will appear.

3 Adjust the setting.


- Press the ▲▼ buttons to choose an option, then press the ◀▶ buttons while watching the screen to adjust the setting.
- Press the (FUNC SET) button.

4 Shoot.

Brightness	You can adjust the brightness of the image. The more to the right, the brighter the image gets, the more to the left, the darker the image gets.
Color	You can change the color of the image. The more to the right, the more vivid the image gets, the more to the left, the more neutral the image gets.
Tone	You can adjust the tone of the image.The more to the right, the stronger the warm red tones get, the more to the left, the the stronger the cool blue tones get.

Shooting in Discreet Mode

You can shoot with camera sounds muted, and the flash and lamp deactivated. Use this mode in areas where camera sounds, lights and flash are not permitted.



1 Set the camera to mode.


- Set the mode dial to .

2 Shoot.

When the camera is set to mode, sounds will remain muted even when in Playback mode. Operation sounds will be muted, and audio will not play back when viewing movies.

Adding Effects and Shooting (Creative Filters)

You can add various effects to images when shooting.



1 Set the camera to mode.

- Set the mode dial to .



2 Choose a Shooting mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose .
- Press the ◀▶ buttons to choose a Shooting mode, then press the (FUNC SET) button.

3 Shoot.

Since you may not achieve the expected results with images shot in , , , and , try taking some test shots first.



Shoot images with vivid colors (Super Vivid)

- Lets you take shots with vivid, intense colors.



Take posterized shots (Poster Effect)

- Lets you take shots that look like an old poster or illustration.

Shoot with the Effects of a Fish-Eye Lens (Fish-eye Effect)

Lets you shoot with the distorting effect of a fish-eye lens.



1 Choose .

- Follow Steps 1 – 2 on p. 68 to choose .

2 Choose an effect level.

- Press the DISP. button.
- ▶ [Effect Level] will appear on the screen.
- Press the ◀▶ buttons to choose an effect level, then press the DISP. button.
- ▶ You can check the effect on the screen.

3 Shoot.

Take Shots That Look Like a Miniature Model (Miniature Effect)

Blurs chosen portions in the top and bottom of an image to produce the effect of a miniature model.

1 Choose .

- Follow Steps 1 – 2 on p. 68 to choose .
- A white frame (the area that will not be blurred) appears on the screen.



2 Choose the area to keep in focus.

- Press the DISP. button.
- Move the zoom lever to change the frame size, and press the ▲▼ buttons to change the frame position, then press the DISP. button.

3 Shoot.

- If you press the (FUNC SET) button in Step 2, the horizontal/vertical orientation of the frame will switch, and you can press the ◀▶ buttons to change the frame position when it is displayed vertically.
- Holding the camera vertically will change the orientation of the frame.

Shoot with the Effects of a Toy Camera (Toy Camera Effect)

This effect darkens and blurs the corners of the image, and changes the overall color so that it looks like an image shot with a toy camera.



1 Choose 📷.

- Follow Steps 1 – 2 on p. 68 to choose 📷.

2 Choose a color tone.

- Press the DISP. button.
- ▶ [Color Tone] will appear on the screen.
- Press the ◀▶ buttons to choose a color tone, then press the DISP. button.
- ▶ You can check the color tone on the screen.

3 Shoot.

Standard	Images will look like they were shot with a toy camera.
Warm	Gives images a warmer tone than [Standard].
Cool	Gives images a cooler tone than [Standard].

Shooting in Monochrome

You can shoot images in black and white, sepia or blue and white.



1 Choose ◪.

- Follow Steps 1 – 2 on p. 68 to choose ◪.

2 Choose a color tone.

- Press the DISP. button.
- ▶ [Color Tone] will appear on the screen.
- Press the ◀▶ buttons to choose a color tone, then press the DISP. button.
- ▶ You can check the color tone on the screen.

3 Shoot.

B/W	Lets you shoot black and white images.
Sepia	Lets you shoot sepia toned images.
Blue	Lets you shoot blue and white images.

Detecting a Face and Shooting (Smart Shutter)

Detecting a Smile and Shooting

The camera will shoot, even without pressing the shutter button, when it detects a smile.



1 Choose .

- Follow Steps 1 – 2 on p. 64 to choose , then press the DISP. button.
- Press the ◀▶ buttons to choose , then press the DISP. button.

▶ The camera will enter shooting stand-by, and [Smile Detection on] will appear on the screen.



2 Point the camera at a person.

- Each time the camera detects a smile it will shoot after the lamp lights.
- Press the ▼ button to pause smile detection. Press the ▼ button again to resume smile detection.

What if a smile is not detected?

Smiles are easier to detect if the subject faces the camera, and opens their mouth enough to show some teeth when smiling.

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

- You should switch to another mode when you finish shooting, or the camera will continue taking shots each time the camera detects a smile.
- You can also shoot by pressing the shutter button.

Using the Wink Self-Timer

Point the camera at a person and press the shutter button fully. The camera will shoot approximately two seconds after it detects a wink.




1 Choose .

- Follow Steps 1 – 2 on p. 64 to choose , then press the DISP. button.
- Press the ◀▶ buttons to choose , then press the DISP. button.

2 Compose the shot and press the shutter button halfway.

- Confirm that a green frame appears around the face of the person who will wink.



3 Press the shutter button fully.

- The camera will enter shooting stand-by, and [Wink to take picture] will appear on the screen.
- The lamp will blink and the self-timer sound will play.



4 Face the camera and wink.

- The shutter will release approximately 2 seconds after a wink is detected from the person inside the frame.
- To cancel the countdown, press the ▼ button.

What if a wink is not detected?

- Wink a bit slowly.
- A wink may not be detected if eyes are covered by hair or a hat, or when wearing glasses.

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

- Shutting both eyes will also be detected as a wink.
- If a wink is not detected, the shutter will release approximately 15 seconds later.
- If there are no people in the shot when the shutter button is pressed fully, the camera will shoot after a person enters the shot and winks.

Using the Face Self-Timer

The shutter will release approximately two seconds after the camera detects a new face (p. 88). You can use this when the photographer wants to be in the image, such as a group photo.




1 Choose .

- Follow Steps 1 – 2 on p. 64 to choose , then press the DISP. button.
- Press the ◀▶ buttons to choose , then press the DISP. button.

2 Compose the shot and press the shutter button halfway.

- Make sure a green frame appears on the face focused on and white frames appear on other faces.



3 Press the shutter button fully.

- The camera will enter shooting stand-by, and [Look straight at camera to start count down] will appear on the screen.
- The lamp will blink and the self-timer sound will play.



4 Join the subjects and look at the camera.

- When the camera detects a new face, the lamp and self-timer sound will speed up (the lamp remains lit when the flash will fire), and two seconds later the shutter will release.
- To cancel shooting with the timer after countdown has started, press the ▼ button.

Changing the number of shots

After choosing in Step 1, press the ▲▼ buttons.

Even if your face is not detected after joining the subjects, the shutter will release approximately 15 seconds later.


Shooting Long Exposures

You can set the shutter speed to a range between 1 and 15 seconds to shoot long exposures. However, you should attach the camera to a tripod to prevent the camera from moving and blurring the image.



1 Choose ★.

- Follow Steps 1 – 2 on p. 64 to choose ★.



2 Choose the shutter speed.

- Press the ▲ button.
- Press the ◀▶ buttons to choose the shutter speed, then press the (FUNC SET) button.

3 Confirm the exposure.

- When you press the shutter button halfway, the exposure for the chosen shutter speed will appear on the screen.


- The brightness of the image may differ from the brightness of the screen in Step 3 when the shutter button was pressed halfway.
- When shutter speeds of 1.3 seconds or slower are used, images are processed to eliminate noise after being taken. A certain amount of processing time may be needed before you can take the next shot.

If the flash fires, the image may be overexposed. If this happens, set the flash to ⊗ and shoot.

5

Choosing Settings Yourself

In this chapter you will learn how to use the various functions in **P** mode to progressively advance your shooting skills.



- This chapter assumes that you have set the mode dial to **P** mode.
- **P** stands for Program AE.
- Before attempting to shoot using a function explained in this chapter in modes other than **P** mode, check if the function is available in those modes (pp. 168 – 175).

Shooting in Program AE

You can choose the settings for various functions to suit your preferences. AE stands for Auto Exposure. The focusing range is approximately 5 cm (2.0 in.) – infinity at maximum wide angle (), and approximately 80 cm (2.6 ft.) – infinity at maximum telephoto ().



1 Enter P mode.

- Set the mode dial to **P**.

2 Adjust the settings according to your purposes (pp. 81 – 99).

3 Shoot.

What if the shutter speed and aperture value appear in orange?

If a correct exposure cannot be obtained when pressing the shutter button halfway, the shutter speed and aperture value appear in orange. Try the following settings to obtain the correct exposure.

- Turn on the flash (p. 81)
- Choose a higher ISO speed (p. 83)

Adjusting the Brightness (Exposure Compensation)

You can adjust the standard exposure set by the camera in 1/3-stop increments in the range of -2 to +2.



1 Enter Exposure Compensation mode.

- Press the ▲ button.

2 Adjust the brightness.

- While watching the screen, press the ◀▶ buttons to adjust the brightness, then press the (FUNC SET) button.
- ▶ The exposure compensation amount will appear on the screen.

Turning the Flash On

You can make the flash fire every time you shoot. The effective flash range is approximately 30 cm – 4.0 m (12 in. – 13 ft.) at maximum wide angle ([W]), and approximately 50 cm – 2.0 m (1.6 – 6.6 ft.) at maximum telephoto ([T]).



Choose ϟ.

- After pressing the ▶ button, press the ◀▶ buttons to choose ϟ, then press the (FUNC SET) button.
- ▶ Once set, ϟ will appear on the screen.

Adjusting the White Balance

The white balance (WB) function sets the optimal white balance for natural looking colors to match the shooting conditions.



1 Choose the white balance function.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose AWB.

2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

AWB Auto	Automatically sets the optimal white balance for the shooting conditions.
Day Light	For shooting outdoors, in fine weather conditions.
Cloudy	For shooting in cloudy, shady or twilight conditions.
Tungsten	For shooting under tungsten and bulb-type (3-wavelength) fluorescent lighting.
Fluorescent	For shooting under warm-white fluorescent, cool-white fluorescent and warm-white-type (3-wavelength) fluorescent lighting.
Fluorescent H	For shooting under daylight fluorescent and daylight-type (3-wavelength) fluorescent lighting.
Custom	For manually setting a custom white balance.

Custom White Balance

You can adjust the white balance to match the light source at the shooting location. Make sure that you set the white balance under the light source of the actual scene you will shoot.



- In Step 2 above, choose .
- Make sure the entire screen is filled with a plain, white colored subject, then press the DISP. button.
- ▶ The tint on the screen will change when white balance data is set.

If you change camera settings after recording white balance data, the tone may not turn out properly.

Changing the ISO Speed



1 Choose the ISO speed.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose ISO AUTO.

2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.

▶ The setting will appear on the screen.

ISO AUTO		Automatically adjusts the ISO speed to the Shooting mode and shooting conditions.
ISO 80 ISO 100 ISO 200	Low ↕ High	For shooting outdoors, in fine weather conditions.
ISO 400 ISO 800		For shooting in cloudy, or twilight conditions.
ISO 1600		For shooting nightscapes, or in dark interiors.

Changing the ISO speed

- Lowering the ISO speed results in sharper images, but there may be an increased chance of image blurring in certain shooting conditions.
- Raising the ISO speed results in a faster shutter speed, reducing image blurring and letting the flash reach greater distances to the subject. The images, however, will appear coarse.

When the camera is set to ISO AUTO, you can press the shutter button halfway to display the automatically set ISO speed.

Correcting the Brightness and Shooting (i-Contrast)

The camera can detect areas in the scene, such as faces or backgrounds, that are too bright or dark and automatically adjust them to the optimum brightness when shooting. Also, when the overall image is lacking in contrast, the camera will automatically correct the image for a sharper impression when shooting.



Choose [i-Contrast].

- Press the MENU button to choose [i-Contrast] from the tab, then press the ◀▶ buttons to choose [Auto].
- Once set, will appear on the screen.

- Under some conditions, the image may appear coarse or may not be corrected properly.
- You can correct recorded images (p. 129).

Continuous Shooting

You can shoot continuously at a maximum speed of approximately 1.0 images/second while the shutter button is pressed fully and held.



1 Choose a Drive mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose □.

2 Choose an option.

- Press the ◀▶ buttons to choose 🖳, then press the (FUNC SET) button.
- Once set, 🖳 will appear on the screen.

3 Shoot.

- As long as you hold the shutter button down, the camera will shoot successive images.

- Cannot be used with the self-timer (pp. 58, 59, 60).
- In (👤) (p. 64) and ✨ (p. 65) modes, continuous shooting speed increases.
- For continuous shooting, the focus and exposure are locked when the shutter button is pressed halfway.
- Depending on the shooting conditions and the camera settings, the camera may stop shooting momentarily, or the shooting speed may slow down.
- As the number of images increases, the shooting speed may slow down.
- If the flash fires, the shooting speed may slow down.

Changing the Tone of an Image (My Colors)

You can change the tone of an image, for example to sepia or black and white, when shooting.



1 Choose My Colors.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose MY COLORS OFF.

2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ The setting will appear on the screen.

MY COLORS OFF My Colors Off	—
MY COLORS V Vivid	Emphasizes the contrast and color saturation for a vivid impression.
MY COLORS N Neutral	Tones down the contrast and color saturation for neutral hues.
MY COLORS Se Sepia	Changes the image to sepia tones.
MY COLORS BW B/W	Changes the image to black and white.
MY COLORS C Custom Color	You can adjust contrast, sharpness, and color saturation etc. to your preference.

The white balance cannot be set in MY COLORS Se and MY COLORS BW (p. 82).

Custom Color

The contrast, sharpness, and color saturation in an image can be chosen and set at 5 different levels.



- Follow Step 2 above to choose MY COLORS C, then press the DISP. button.
- Press the ▲▼ buttons to choose an option, then press the ◀▶ buttons to choose a value.
- The more to the right, the stronger/deeper the effect gets, the more to the left, the weaker/lighter the effect gets.
- Press the DISP. button to complete the setting.

Shooting Close-ups (Macro)

You can shoot an object at a close distance or even shoot extreme close-ups of it. The focusing range is approximately 3 – 50 cm (1.2 in. – 1.6 ft.) from the end of the lens at maximum wide angle ( ).



Choose .

- After pressing the ◀ button, press the ◀▶ buttons to choose , then press the (FUNC SET) button.
- ▶ Once set, will appear on the screen.

The edges of the image may darken if the flash fires.

How can I take better close-ups?

Try attaching the camera to a tripod and shooting in to prevent the camera from moving and blurring the image (p. 59).

will turn gray in the area that displays in the yellow bar underneath the zoom bar, and the camera will not focus.

Shooting Far Away Subjects (Infinity)

When it is difficult to focus because your shot contains subjects that are both near and far, you can change the focusing range to focus more reliably on far away subjects (approx. 3.0 m (9.8. ft.) or more from the camera) only.




Choose .

- After pressing the ◀ button, press the ◀▶ buttons to choose , then press the (FUNC SET) button.
- ▶ Once set, will appear on the screen.

Changing the AF Frame Mode

You can change the AF (Auto Focus) frame mode to match the scene you want to shoot.



Choose [AF Frame].

- Press the MENU button to choose [AF Frame] from the tab, then press the ◀▶ buttons to choose an option.

Face AiAF

- Detects people's faces and sets the focus, exposure (evaluative metering only) and white balance (AWB only).
- When the camera is pointed at subjects, a white frame appears on the face the camera judges to be the main subject, and gray frames (max. 2) will appear on other faces.
- A frame will follow a moving subject within a certain range.
- When the shutter button is pressed halfway, up to 9 green frames will appear on faces that the camera focuses on.

- If a face is not detected, or only gray frames (no white frame) appear, up to 9 green frames will appear on the areas the camera focuses on when the shutter button is pressed halfway.
- If a face is not detected when Servo AF (p. 93) is set to [On], the AF frame will appear in the center of the screen when you press the shutter button halfway.
- Examples of faces that cannot be detected:
  - Subjects that are far away or extremely close
  - Subjects that are dark or light
  - Faces turned to the side or at an angle, or faces with a portion hidden
- The camera may mistakenly identify non-human subjects as a face.
- If the camera cannot focus when you press the shutter button halfway, the AF frame will not appear.

Tracking AF

You can choose the subject you want to focus on and shoot (p. 90).

Center

The AF frame is locked to the center. This is effective for focusing on a specific point.

You can reduce the AF frame size

- Press the MENU button to choose [AF Frame Size] from the tab, then choose [Small].
- The AF frame is set to [Normal] when using the digital zoom (p. 55) or digital tele-converter (p. 56).

If the camera cannot focus when you press the shutter button halfway, the AF frame will turn yellow and will appear.

Changing the Composition with the Focus Lock

While you keep the shutter button pressed halfway, the focus and exposure are locked. You can now recompose and shoot. This is called Focus Lock.



1 Focus.

- Center the subject you want in focus, and press the shutter button halfway.
- Confirm that the AF frame on the subject is green.



2 Recompose.

- Keep the shutter button pressed halfway and move the camera to recompose the scene.

3 Shoot.

- Press the shutter button fully.

Choosing the Subject to Focus On (Tracking AF)

You can choose the subject you want to focus on and shoot.




1 Choose [Tracking AF].

- Press the MENU button to choose [AF Frame] from the tab, then press the ◀▶ buttons to choose [Tracking AF].
- ▶ ⊹ will appear in the center of the screen.



2 Choose the subject to focus on.

- Point the camera so that ⊹ is on the subject you want to focus on and press the ◀ button.



- ▶ The camera will beep and ⌜ ⌝ ⌞ ⌟ will appear when a subject is detected. The camera will continue to track the subject within a certain range even if the subject moves.
- ▶ If the camera does not detect the subject, ⊹ will appear on the screen.
- To cancel tracking, press the ◀ button again.


3 Shoot.

- Press the shutter button halfway. ⌜ ⌝ ⌞ ⌟ will change into a blue ▭ which will follow the subject while the camera continues to adjust the focus and exposure (Servo AF) (p. 93).
- Press the shutter button fully to shoot.
- ▶ Even after shooting completes, ⌜ ⌝ ⌞ ⌟ will appear, and the camera will continue to track the subject.

- The camera will detect a subject even if you press the shutter button half way without pressing the ◀ button. When shooting completes, ⊹ will appear in the center of the screen.
- Servo AF (p. 93) is fixed to [On].
- The camera may not be able to track the subject if the subject is too small, moves too quickly or if the contrast between the subject and the background is too low.
- Not available in 🌷 or ▲.

Magnifying the Focal Point

If you press the shutter button halfway, the AF frame will magnify and you can check the focus.



1 Choose [AF-Point Zoom].

- Press the MENU button to choose [AF-Point Zoom] from the 📷 tab, then press the ◀▶ buttons to choose [On].



2 Check the focus.

- Press the shutter button halfway.
- ▶ In [Face AiAF] (p. 88), the face detected as the main subject will appear magnified.
- ▶ In [Center] (p. 89), the contents of the center AF frame will appear magnified.

What if the display does not magnify?

The display will not appear magnified in [Face AiAF] if a face cannot be detected or is too big in relation to the screen. In [Center], it will not appear magnified if the camera cannot focus.

The magnified display will not appear when using the digital zoom (p. 55), digital tele-converter (p. 56), Tracking AF (p. 89), Servo AF (p. 93) or when using a TV as a display (p. 100).

Shooting with the AF Lock

The focus can be locked. After locking the focus, the focal distance will not change even when you release your finger from the shutter button.



1 Lock the focus.

- Keep the shutter button pressed halfway and press the ◀ button.
- ▶ The focus locks and AFL appears on the screen.
- If you release your finger from the shutter button and press the ◀ button again, AFL will disappear and the focus will unlock.

2 Compose the scene and shoot.

Shooting with Servo AF

While the shutter button is pressed halfway, the focus and exposure will continue to adjust, allowing you to take pictures of moving subjects without missing a shot.



1 Choose [Servo AF].

- Press the MENU button to choose [Servo AF] from the tab, then press the ◀▶ buttons to choose [On].

2 Focus.

- The focus and exposure will be maintained where the blue AF frame appears while you press the shutter button halfway.

- The camera may not be able to focus in some conditions.
- In low light conditions, AF frames may not turn blue even after pressing the shutter button halfway. In this case, you can set the focus and exposure with the AF frame setting.
- If a correct exposure cannot be obtained, the shutter speed and aperture value appear in orange. Release your finger from the shutter button, then press it again halfway.
- You cannot shoot with the AF lock in this mode.
- The [AF-Point Zoom] option in the tab is not available in Servo AF mode.
- Not available when using the self-timer (pp. 58, 59, 60).

Choosing the Person to Focus On (Face Select)

You can choose a specific person's face to focus on and then shoot.



1 Enter Face Select mode.

- Point the camera toward the face of the subject and press the [face] button.
- ▶ After [Face Select : On] appears, a face frame will appear around the face detected as the main subject.
- Even if the subject moves, the face frame will follow the subject within a certain range.
- If a face is not detected, will not appear.



2 Choose the face to focus on.

- If you press the [face] button, the face frame will move to another face detected by the camera.
- When the frame has made a full circuit of all detected faces, [Face Select : Off] will appear, and the AF frame mode screen will reappear.



3 Shoot.

- Press the shutter button halfway. When the camera focuses, will change into .
- Press the shutter button fully to shoot.

Changing the Metering Method

You can change the metering method (brightness measuring function) to match the shooting conditions.



1 Choose the metering method.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose [⊙].

2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.

▶ The setting will appear on the screen.

[⊙]	Evaluative	For standard shooting conditions, including back lit shots. Automatically adjusts the exposure to match the shooting conditions.
[ ]	Center Weighted Avg.	Averages the light metered from the entire frame, but gives greater weight to the center.
[•]	Spot	Only meters within the [ ] (Spot AE Point frame) that appears at the center of the screen.

Shooting with the AE Lock

You can lock the exposure and shoot, or set the focus and exposure separately to shoot. AE stands for “Auto Exposure”.



1 Choose ⚡ (p. 54).

2 Lock the exposure.

- Point the camera toward the subject and press the ▲ button while pressing the shutter button halfway.
- ▶ When AEL appears, the exposure will be locked.
- If you release your finger from the shutter button and press the ▲ button again, AEL will disappear and AE will unlock.

3 Compose the scene and shoot.

Shooting with the FE Lock

Just as with the AE lock, you can lock the exposure for shooting with the flash. FE stands for “Flash Exposure”.



1 Choose ϟ (p. 81).

2 Lock the flash exposure.

- Point the camera toward the subject and press the ▲ button while pressing the shutter button halfway.
- ▶ The flash will fire and when FEL appears, the flash output will be retained.
- If you release your finger from the shutter button and press the ▲ button again, FEL will disappear and FE will unlock.

3 Compose the scene and shoot.

Shooting with Slow Synchro

You can make the main subject, such as people, appear bright by having the camera provide the appropriate illumination with the flash. At the same time, you can use a slow shutter speed to brighten the background that the light from the flash cannot reach.



1 Choose ⚡.

- After pressing the ▶ button, press the ◀▶ buttons to choose ⚡, then press the (FUNC SET) button.
- ▶ Once set, ⚡ will appear on the screen.


2 Shoot.

- Even if the flash fires, ensure that the main subject does not move until the shutter sound ends.

Attach the camera to a tripod to prevent the camera from moving and blurring the image.


Red-Eye Correction

You can automatically correct red-eye that occurs in images taken with the flash.



1 Choose [Flash Settings].

- Press the MENU button to choose [Flash Settings] from the tab, then press the (FUNC SET) button.



2 Choose the setting.

- Press the ▲▼ buttons to choose [Red-Eye Corr.], then press the ◀▶ buttons to choose [On].
- ▶ Once set, ⊙ will appear on the screen.

Red-eye correction may be applied to areas other than red eyes. For example, when red make-up has been used around eyes.

- You can also correct recorded images (p. 129).
- You can also display the screen in Step 2 by pressing the ▶ button, then the MENU button.

Checking for Shut Eyes

When the camera detects the possibility that people have their eyes shut, appears on the screen.



1 Choose [Blink Detection].

- Press the MENU button to choose [Blink Detection] from the tab, then press the ◀▶ buttons to choose [On].

2 Shoot.

- When a person with shut eyes is detected, a frame and appear on the screen.

- This function is only available for the last image shot when you have set the camera to 2 or more shots in or mode.
- Not available in mode.

Shooting Using the Viewfinder

If you want to save battery power, you can use the viewfinder for shooting instead of the screen. Shooting procedures are the same as when using the screen. The camera will automatically focus on subjects, but it will not detect and focus on faces.

1 Turn off the screen.

- Press the DISP. button to turn off the screen (p. 43).

2 Compose the scene and shoot.

- Look into the viewfinder to compose the scene and shoot.

The area visible in the viewfinder may differ slightly from the image taken.

You may be able to see part of the lens through the viewfinder depending on the zoom position.

Shooting Using a TV as the Display


You can use a TV to display the camera screen content while shooting.

- To connect the camera to a TV, follow the Steps in “Viewing Images on a TV” (p. 116).
- Shooting procedures are the same as when using the camera screen.

6

Using Various Functions for Shooting Movies

This chapter serves as a more advanced version of the “Shooting Movies” and “Viewing Movies” sections in Chapter 1, and explains how to use various functions for shooting and viewing movies.



- This chapter assumes that you have set the mode dial to .
- The latter half of the chapter explaining movie playback and editing assumes that you have pressed the button to enter Playback mode.

Changing the Movie Mode

You can choose among 2 different Movie modes.



Choose a Movie mode.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose .
- Press the ◀▶ buttons to choose a Movie mode, then press the (FUNC SET) button.

	Standard	For shooting standard movies.
	Miniature Effect	You can shoot movies that look like a miniature model (p. 102).

Shoot Movies That Look Like a Miniature Model (Miniature Effect)

You can shoot movies that look like moving miniature models. You create the miniature model effect by choosing the upper and lower portions of the scene that will be blurred, and the playback speed, which makes people and objects in the scene move quickly during playback. Audio will not be recorded.

1 Choose .

- Follow the steps above to choose .
- ▶ A white frame (the area that will not be blurred) appears on the screen.



2 Choose the area to keep in focus.

- Press the DISP. button.
- Move the zoom lever to change the frame size, and press the ▲▼ buttons to change the frame position.



3 Choose a playback speed.

- Press the MENU button.
- Press the ◀▶ buttons to choose a playback speed.
- Press the MENU button to complete the setting and restore the shooting screen.

4 Shoot.

Playback Speeds and Estimated Playback Times (for 1 Min. Clips)

Speed	Playback Time
5x	Approx. 12 sec.
10x	Approx. 6 sec.
20x	Approx. 3 sec.

- If you press the (FUNC/SET) button in Step 2, the horizontal/vertical orientation of the frame will switch, and you can press the ◀▶ buttons to change the frame position when it is displayed vertically.
- Holding the camera vertically will change the orientation of the frame.
- Since you may not achieve the expected results depending on the shooting conditions, try taking some test shots first.

Changing the Image Quality

You can choose among 3 different image quality settings.



1 Choose the image quality setting.

- After pressing the (FUNC SET) button, press the ▲▼ buttons to choose 1280.

2 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ The option you set will appear on the screen.

Image Quality and Shooting Time per Memory Card

Image Quality	Recording Pixels, Frame Rate	Content	Memory Card Capacity	
			4 GB	16 GB
1280	1280 x 720 pixels, 24 frames/sec.*	For shooting high-definition movies.	Approx. 26 min. 48 sec.	Approx. 1 hr. 49 min. 48 sec.
640	640 x 480 pixels, 30 frames/sec.	The image quality will be higher when compared with 320, but the recording time will be shorter.	Approx. 50 min. 17 sec.	Approx. 3 hr. 25 min. 54 sec.
320	320 x 240 pixels, 30 frames/sec.	Since the file size is small, shooting time will increase, but the image quality will decrease.	Approx. 3 hr. 2 min. 52 sec.	Approx. 12 hr. 28 min. 47 sec.

* movies play back at 30 fps.

- Based on Canon's testing standards.
- Recording will automatically stop when the clip file size reaches 4 GB, or when the recording time reaches approximately 10 minutes when shooting in 1280, and approximately 1 hour when shooting in 640 or 320.
- Recording may stop even if the maximum clip length has not been reached on some memory cards. SD Speed Class 4 or higher memory cards are recommended.

AE Lock/Exposure Shift

You can lock the exposure or change it in 1/3 steps within a range of ±2 before shooting.



1 Focus.

- Press the shutter button halfway to focus.

2 Lock the exposure.

- After releasing the shutter button, press the ▲ button to lock the exposure. The exposure shift bar appears.
- Press the ▲ button again to release the lock.

3 Change the exposure.

- While watching the screen, press the ◀▶ buttons to adjust the exposure.

4 Shoot.

Other Shooting Functions

The following functions can be used in the same way as for still images. Some functions, however, may not be available depending on the Shooting mode. Refer to “Functions Available in Each Shooting Mode” and “Shooting Menu” (pp. 168 – 175).

- **Zooming in More Closely On Subjects**
  The optical zoom is not available while shooting. Be sure to set the optical zoom before shooting.
- **Using the Self-Timer** (p. 58)
  The number of shots cannot be set.
- **Adjusting the White Balance** (p. 82)
- **Changing the Tone of an Image (My Colors)** (p. 86)
- **Shooting Close-ups (Macro)** (p. 87)
- **Shooting Far Away Subjects (Infinity)** (p. 87)
- **Shooting with the AF Lock** (p. 92)
- **Shooting Using a TV as the Display** (p. 100)
- **Turning Off the AF Assist Beam** (p. 151)
- **Displaying the Overlay** (p. 153)

Editing

You can trim the beginnings and ends of recorded movies.



Movie Editing Panel



Movie Editing Bar

1 Choose ✂.

- Follow Steps 1 – 3 on p. 31 to choose ✂, then press the (FUNC SET) button.
- ▶ The movie editing panel and the movie editing bar will appear.

2 Set the editing range.

- Press the ▲▼ buttons and choose ✂ or ✂.
- If you press the ◀▶ buttons to move ▮, ✂ will appear at points where the movie can be edited. If you choose ✂, you can trim the beginning of the movie from ✂. If you choose ✂, you can trim the end of the movie from ✂.
- Even if you move ▮ to a point other than a ✂, only the portion from the nearest ✂ to the left will be trimmed when ✂ is chosen. Only the portion from the nearest ✂ to the right will be trimmed when ✂ is chosen.

3 Check the edited movie.

- Press the ▲▼ buttons to choose ▶ (Play), then press the (FUNC SET) button. The edited movie will play.
- To edit the movie again, repeat Step 2.
- To cancel editing, press the ▲▼ buttons to choose ↩. After pressing the (FUNC SET) button, press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button again.



4 Save the edited movie.

- Press the ▲▼ buttons to choose [↻], then press the (FUNC SET) button.
- Press the ◀▶ buttons to choose [New File], then press the (FUNC SET) button.

▶ The movie will be saved as a new file.

- When [Overwrite] is chosen in Step 4, the unedited movie is overwritten with the edited movie, erasing the original.
- When there is not enough space left on the memory card, only [Overwrite] can be chosen.
- If the batteries are depleted partway through saving, the edited movie clips may not be saved.
- When editing movies, you should use batteries with sufficient charge, fully charged NiMH AA batteries or a compact power adapter (both sold separately) (p. 37).

7

Using Various Playback and Editing Functions

This chapter explains various ways to play back and edit images.

- Press the ▶ button to enter Playback mode before operating the camera.

- It may not be possible to play back or edit images that have been edited on a computer, have had their file names changed, or have been taken on a different camera.
- The edit function (pp. 126 – 130) cannot be used if the memory card does not have enough free space available.

Quickly Searching Images

Searching Images Using Index Display

Displaying multiple images at the same time lets you quickly find the image you want.



1 Move the zoom lever toward .

- Images will display in an index.
- The number of images increase each time you move the lever toward .
- The number of images decrease each time you move the lever toward Q.



2 Choose an image.

- Press the ▲▼◀▶ buttons to choose an image.
- An orange frame appears on the chosen image.
- Press the (FUNC SET) button to display the chosen image by itself.

Searching Images by Scrolling

Pressing the ◀▶ buttons for more than 1 second will display images in a line letting you quickly search them. You can also jump by the shooting date (Scroll Display).



Choose an image.

- If you set the camera to single image playback and press the ◀▶ buttons for more than 1 second, the screen at the left will appear. Press the ◀▶ buttons to choose an image.
- Press the (FUNC SET) button to restore single image playback.
- Press the ▲▼ buttons during scroll display to search images by the shooting date.

To turn off this effect, press the MENU button to choose [Scroll Display] from the ▶ tab, then choose [Off].

Searching for Images Using the Jump Display

When there are many images on the memory card, you can search them by a specified method or image unit.





Position of currently displayed image

1 Choose a jump method.

- In single image playback, press the ▲ button.
- ▶ The jump method and the position of the currently displayed image will appear at the bottom of the screen.
- Press the ▲▼ buttons to choose the desired jump method.

2 Switch images.

- Press the ◀▶ buttons.
- ▶ Images will switch according to the chosen jump method.
- To return to single image playback, press the MENU button.

Jump to Favorites	Displays the images tagged as favorites (p. 122).
Jump 10 Images	Jumps over 10 images at a time.
Jump 100 Images	Jumps over 100 images at a time.
Jump Shot Date	Jumps to the first image in each shooting date group.
Jump to My Category	Displays images in each category (p. 123).
Jump to first	Jumps to still images only.
Jump to Movie	Jumps to movies only.

- The number of images matching the jump method will display on the right side of the screen except for 10 and 100.

If there are no images matching the jump method, the ◀▶ buttons will not function.

Viewing Slideshows

You can automatically play back images recorded to a memory card.



1 Choose [Slideshow].

- Press the MENU button to choose [Slideshow] from the ▶ tab, then press the (FUNC SET) button.



2 Choose a setting.

- Press the ▲▼ buttons to choose a menu item, then press the ◀▶ buttons to choose an option.

Repeat	Repeats playback of images
Play Time	Display time for each image
Effect	Transition effects when switching between images


3 Choose [Start].

- Press the ▲▼ buttons to choose [Start], then press the (FUNC SET) button.
- ▶ The slideshow will start a few seconds after [Loading image...] displays.
- You can pause/restart a slideshow by pressing the (FUNC SET) button again.
- Press the MENU button to stop the slideshow.

- If you press the ◀▶ buttons during playback, the image will switch. If you keep the ◀▶ buttons pressed, you can fast-forward through images.
- The power saving function (p. 51) does not work during slideshows.
- You cannot change [Play Time] if [Bubble] is chosen in [Effect].

Checking the Focus

You can magnify the area of a recorded image that was inside the AF Frame to check the focus.



1 Press the DISP. button to switch to the focus check display (p. 43).

- For images with detected faces, you can also switch to the focus check display by pressing the [ ] button.
- ▶ A white frame will appear where the AF frame was when the focus was set.
- ▶ A gray frame will appear on a face detected during playback.
- ▶ The area within the orange frame appears magnified.



2 Switch frames.

- Move the zoom lever toward Q once.
- ▶ The screen shown on the left will appear.
- Press the [ ] button to switch between frames on detected faces. Press the (FUNC. SET) button to move to other frames.

3 Change the magnification level or location.

- Use the zoom lever to change the display size, and the ▲▼◀▶ buttons to change the display position while checking the focus.
- Press the MENU button to reset the display to Step 1.



The focus check display is not available for movies.

Magnifying Images





Approximate Location of Displayed Area


Move the zoom lever toward Q.

- The display will zoom in on the image and SET will appear. If you continue to hold the zoom lever, it will zoom in up to a maximum factor of approximately 10x.
- If you press the ▲▼◀▶ buttons, you can move the location of the displayed area.
- Move the zoom lever toward ▪ to zoom out, or continue to hold it to return to single image playback.
- When SET appears on the screen, press the (FUNC SET) button to switch to SET. Press the ◀▶ buttons to switch between images while zoomed. Press the (FUNC SET) button again to return to the original setting.

- In magnified display, pressing the MENU button restores single image playback.
- Movies cannot be magnified.

Displaying Various Images (Smart Shuffle)

The camera will choose four images based on the displayed image.
If you choose one of those images, the camera will select four more images letting you enjoy playing back images in an unexpected order.
This will work best if you take many shots of various scenes.



1 Choose [Smart Shuffle].

- Press the MENU button to choose [Smart Shuffle] from the ▶ tab, then press the (FUNC SET) button.
- ▶ Four images will appear as possibilities.




2 Choose an image.

- Press the ▲▼◀▶ buttons to choose the image you want to view next.
- The chosen image will be displayed in the middle, and the next four possibilities will appear.
- Press the (FUNC SET) button to display the middle image at full size. Press the (FUNC SET) button again to restore the original display.
- Press the MENU button to restore single image playback.

- Only still images shot with this camera will play back in Smart Shuffle.
- Smart Shuffle is not available in the following situations:
  - If there are less than 50 images taken with this camera on the memory card
  - If you play back images not supported by Smart Shuffle
  - During filtered playback

Changing Image Transitions

You can choose from 3 transition effects when switching between images in single image playback.




Choose [Transition].

- Press the MENU button to choose [Transition] from the ▶ tab, then press the ◀▶ buttons to choose a transition effect.

Viewing Images on a TV


Using the separately sold AV cable (p. 2), you can connect the camera to a TV to view images you have shot.

1 Turn off the camera and TV.




2 Connect the camera to the TV.

- Open the camera's terminal cover and fully insert the cable plug into the camera's terminal.



- Insert the cable plug fully into the video input terminals as shown in the illustration.

3 Turn on the TV and switch it to the input the cable is connected to.



4 Turn on the camera.

- Press the ▶ button to turn on the camera.
- ▶ The image will appear on the TV (nothing will appear on the screen of the camera).
- After you finish, turn off the camera and TV, and unplug the cable.

What if the images don't display correctly on the TV?

Images will not display correctly if the camera's video output setting (NTSC/PAL) does not match the TV system. Press the MENU button and choose [Video System] from the 🔧 tab to switch to the correct video system.

Protecting Images

You can protect important images so that they cannot be accidentally erased with the camera (pp. 27, 120).

Choose a selection method



1 Choose [Protect].

- Press the MENU button to choose [Protect] from the ▶ tab, then press the (FUNC SET) button.



2 Choose a selection method.

- Press the ▲▼ buttons to choose a selection method, then press the (FUNC SET) button.
- Press the MENU button to complete the setting and restore the menu screen.

If you format the memory card (pp. 21, 145), protected images will also be erased.

Protected images cannot be erased with the camera's erase function. To erase an image, cancel protection settings first.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select], then press the (FUNC SET) button.



2 Choose images.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- ▶ 🔑 will appear on the screen.
- Press the (FUNC SET) button again to deselect the image. 🔑 will disappear.
- To choose additional images, repeat the above procedure.



3 Protect the image.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.

If you switch to Shooting mode or turn off the power before performing the operations in Step 3, images will not be protected.

Select Range

1 Choose [Select Range].

- Follow Step 2 on p. 117 to choose [Select Range], then press the (FUNC SET) button.



2 Choose a starting image.

- Press the (FUNC SET) button.



- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.



3 Choose an ending image.

- Press the ▶ button to choose [Last image], then press the (FUNC SET) button.



- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- You cannot choose images before the first image.



4 Protect images.

- Press the ▼ button to choose [Protect], then press the (FUNC SET) button.

Choose All Images

1 Choose [All Images].

- Follow Step 2 on p. 117 to choose [All Images], then press the (FUNC SET) button.



2 Protect images.


- Press the ▲▼ buttons to choose [Protect], then press the (FUNC SET) button.

You can unlock groups of protected images if you choose [Unlock] in Step 4, while in [Select Range] or Step 2 while in [All Images].

Erasing All Images

You can erase all images at once. Since erased images cannot be recovered, exercise adequate caution before erasing. Protected images (p. 117) cannot be erased.

Choose a selection method



1 Choose [Erase].

- Press the MENU button to choose [Erase] from the ▶ tab, then press the (FUNC SET) button.



2 Choose a selection method.

- Press the ▲▼ buttons to choose a selection method, then press the (FUNC SET) button.
- Press the MENU button to restore the menu screen.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select], then press the (FUNC SET) button.



2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- ✓ will appear on the screen.
- Press the (FUNC SET) button again to deselect the image. ✓ will disappear.
- To choose additional images, repeat the above procedure.



3 Erase.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons to choose [OK], then press the (FUNC. SET) button.

Select Range

1 Choose [Select Range].

- Follow Step 2 on p. 120 to choose [Select Range], then press the (FUNC. SET) button.

2 Choose images.

- Follow Steps 2 and 3 on p. 118 to choose images.



3 Erase.

- Press the ▼ button to choose [Erase], then press the (FUNC. SET) button.

Choose All Images



1 Choose [All Images].

- Follow Step 2 on p. 120 to choose [All Images], then press the (FUNC. SET) button.

2 Erase.

- Press the ◀▶ buttons to choose [OK], then press the (FUNC. SET) button.

Tagging Images as Favorites

When you tag images as favorites, you can easily categorize just those images. You can also filter out just those images for viewing (p. 111).



1 Choose [Favorites].

- Press the MENU button to choose [Favorites] from the ▶ tab, then press the (FUNC SET) button.



2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- ▶ ★ will appear on the screen.
- Press the (FUNC SET) button again to untag the image. ★ disappears.
- To choose additional images, repeat the above procedure.



3 Complete the setting.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.

If you switch to Shooting mode or turn off the power before completing the setting in Step 3, images will not be tagged as favorites.

If you use Windows 7 or Windows Vista and transfer tagged images to the computer, they will be given a star rating of 3 (★★★☆☆) (except for movies).

Organizing Images by Category (My Category)

You can organize images into categories, then choose the categories to filter and play back (p. 111).

Images are automatically categorized by shooting condition as they are shot.

- : Images with detected faces, or images shot in or .
- : Images detected as , or in or modes, or images shot in or .
- : Images shot in , or .

Choosing a Selection Method



1 Choose [My Category].

- Press the MENU button to choose [My Category] from the tab, then press the (FUNC SET) button.



2 Choose a selection method.

- Press the ▲▼ buttons to choose a selection method, then press the (FUNC SET) button.
- Press the MENU button to restore the menu screen.

Choosing Images Individually

1 Choose [Select].

- Follow Step 2 above to choose [Select], then press the (FUNC SET) button.



2 Choose an image.

- Press the ◀▶ buttons to choose an image.

3 Choose a category.

- Press the ▲▼ buttons to choose a category, then press the (FUNC SET) button.

▶ ✓ will appear on the screen.
- Press the (FUNC SET) button again to deselect the image. ✓ will disappear.
- To choose additional images, repeat the above procedure.



4 Complete the setting.

- If you press the MENU button, a confirmation screen will appear.
- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.

If you switch to Shooting mode or turn off the power before completing the setting in Step 4, images will not be tagged as My Category.

Select Range

1 Choose [Select Range].

- Follow Step 2 on p. 123 to choose [Select Range], then press the (FUNC SET) button.

2 Choose images.

- Follow Steps 2 and 3 on p. 118 to choose images.



3 Choose a category.

- Press the ▼ button to choose an item, then press the ◀▶ buttons to choose a category.


4 Complete the setting.

- Press the ▼ button to choose [Select], then press the (FUNC SET) button.

If you choose [Deselect] in Step 4, you can deselect all of the images in the [Select Range] category.

Rotating Images

You can change the orientation of an image and save it.



1 Choose [Rotate].

- Press the MENU button to choose [Rotate] from the ▶ tab, then press the (FUNC SET) button.



2 Rotate the image.

- Press the ◀▶ buttons to choose an image.
- ▶ The image will rotate 90° with each press of the (FUNC SET) button.
- Press the MENU button to restore the menu screen.

- Movies with an image quality setting of 1280 cannot be rotated.
- Images cannot be rotated if [Auto Rotate] is set to [Off] (p. 154).

Resizing Images

You can resize images to a lower pixel setting and save the resized image as a separate file.



1 Choose [Resize].

- Press the MENU button to choose [Resize] from the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.




3 Choose an image size.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.
- ▶ [Save new image?] will appear on the screen.



4 Save the new image.

- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.
- ▶ The image will be saved as a new file.



5 Display the new image.

- When you press the MENU button, [Display new image?] will appear on the screen.
- Press the ◀▶ buttons to choose [Yes], then press the (FUNC SET) button.
- ▶ The saved image will be displayed.

- You cannot resize an image to a larger size.
- Images recorded at a pixel setting of W (p. 62), or saved as XS in Step 3 cannot be edited.
- Movies cannot be edited.

Trimming

You can cut out a portion of a recorded image and save it as a new image file.



1 Choose [Trimming].

- Press the MENU button to choose [Trimming] from the ▶ tab, then press the (FUNC. SET) button.

2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC. SET) button.

3 Adjust the trimming area.

- ▶ A frame will appear around the portion of the image to be trimmed.
- ▶ The original image will display in the upper left and the trimmed image will display in the lower right.
- If you move the zoom lever to the left or right, you can change the frame size.
- If you press the ▲▼◀▶ buttons, you can move the frame.
- If you press the DISP. button, you can change the frame orientation.
- In an image with detected faces, gray frames appear around the faces located in the upper left image. The frames can be used for trimming. You can switch between frames by pressing the button.
- After pressing the (FUNC. SET) button, press the ◀▶ buttons to choose [OK], then press the (FUNC. SET) button again.

Trimming Area



Trimming Area Display

Recorded pixels after trimming




4 Save as a new image and display.

- Follow Steps 4 and 5 on p. 126.

- Images recorded at a pixel setting of S or W (p. 62), or images resized to XS (p. 126) cannot be edited.
- The width and height ratio of an image that can be trimmed is fixed at 4:3.
- The number of recorded pixels in a trimmed image will be smaller than before trimming.
- Movies cannot be edited.

Correcting the Brightness (i-Contrast)

The camera can detect areas in an image, such as faces or backgrounds, that are too dark and automatically adjust them to the optimum brightness. Also, when the overall image is lacking in contrast, the camera will automatically correct the image for a sharper impression. You can choose from 4 levels of correction, and save the image as a new file.



1 Choose [i-Contrast].

- Press the MENU button to choose [i-Contrast] from the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.



3 Choose an option.

- Press the ◀▶ buttons to choose an option, then press the (FUNC SET) button.

4 Save as a new image and display.

- Follow Steps 4 and 5 on p. 126.

- Under some conditions, the image may appear coarse or not be corrected properly.
- Repeatedly adjusting the same image may cause it to become coarse.

What if the image wasn't corrected by the [Auto] option as well as you would like?

Choose [Low], [Medium] or [High] and adjust the image.

Movies cannot be corrected.

Correcting the Red-Eye Effect

You can automatically correct red eyes in images and save them as new files.



1 Choose [Red-Eye Correction].

- Press the MENU button to choose [Red-Eye Correction] from the ▶ tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons to choose an image.

3 Correct the image.

- Press the (FUNC SET) button.
- ▶ Red-eye detected by the camera will be corrected and a frame will appear around the corrected portion.
- You can magnify or reduce the size of the image using the procedures in “Magnifying Images” (p. 114).



4 Save as a new image and display.

- Press the ▲▼◀▶ buttons to choose [New File], then press the (FUNC SET) button.
- ▶ The image will be saved as a new file.
- Follow Step 5 on p. 126.

- Some images may not be corrected properly.
- When [Overwrite] in Step 4 is chosen, the uncorrected image is overwritten with the corrected data, erasing the original image.
- Protected images cannot be overwritten.


Movies cannot be corrected.


8

Printing

This chapter explains how to choose images for printing, and print using a Canon-brand PictBridge compliant printer (sold separately).

Canon-Brand PictBridge Compliant Printers






This chapter uses Canon-brand SELPHY CP series printers in the explanations. The displayed screens and available functions will differ depending on the printer. Please also refer to the *Printer User Guide*.

Easy Print


You can easily print the pictures you take by connecting the camera to a PictBridge compliant printer (sold separately) using the supplied interface cable (p. 2).

1 Turn off the camera and printer.




2 Connect the camera to the printer.

- Open the cover and insert the cable's small plug firmly into the camera terminal in the direction shown.



- Insert the cable's large plug into the printer. For connection details, refer to the user guide provided with the printer.

3 Turn on the printer.



4 Turn on the camera.

- Press the ▶ button to turn on the camera.



▶ SET will appear on the screen.



5 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.



6 Print images.

- Press the ▲▼ buttons to choose [Print], then press the (FUNC SET) button.
- ▶ Printing will start.
- If you want to print additional images, repeat Steps 5 and 6 after printing has completed.
- After printing has completed, turn off the camera and printer, and unplug the interface cable.



- Refer to p. 38 for Canon-brand PictBridge compliant printers (sold separately).
- Index printing is not available on certain Canon-brand PictBridge compliant printers (sold separately).

Making Print Settings



1 Connect the camera to the printer.

- Follow Steps 1 – 5 on p. 132 to display the screen on the left.

2 Choose a menu option.

- Press the ▲▼ buttons to choose an option.

3 Choose the option settings.


- Press the ◀▶ buttons to choose the option setting.

	Default	Follows the printer's settings.
	Date	Prints the date.
	File No.	Prints the file number.
	Both	Prints both the date and file no.
	Off	—
	Default	Follows the printer's settings.
	Off	—
	On	Uses shooting information to optimize print settings.
	Red-Eye1	Corrects red-eye.
	Red-Eye2*	Uses [NR], [Face] and [Red-Eye1] to correct the image.
	Vivid*	Greens in trees, and blues in the sky and ocean are enhanced to be more vivid.
	NR*	Reduces image noise.
	Vivid+NR*	Uses both [Vivid] and [NR] to correct the image.
	Face *	Corrects brightness for dark faces,such as in backlit shots.
	No. of Copies	Choose the number of copies.
Trimming	—	Choose the area for printing.
Paper Settings	—	Sets the paper size and layout.

* Only appears when connected to Inkjet printers.

Trimming and Printing (Trimming)

You can cut out a portion of an image for printing.



1 Choose [Trimming].

- Follow Steps 1 – 2 on p. 134 to choose [Trimming], then press the (FUNC SET) button.

▶ A frame will appear around the portion of the image to be trimmed.



2 Choose the trimming area.

- Move the zoom lever to can change the frame size.
- Press the ▲▼◀▶ buttons to change the frame position.
- Press the DISP. button to rotate the frame.
- Press the (FUNC SET) button to complete the setting.

3 Print.

- Follow Step 6 on p. 133 to print.


- You may not be able to trim images depending on the aspect ratio, or if they are too small.
- Trimming photos with embedded dates may not show the dates properly.

Choosing the Paper Size and Layout for Printing



1 Choose [Paper Settings].

- Follow Steps 1 – 2 on p. 134 to choose [Paper Settings], then press the (FUNC SET) button.



2 Choose a paper size.

- Press the ▲▼ buttons to choose an option, then press the (FUNC SET) button.



3 Choose a paper type.

- Press the ▲▼ buttons to choose an option, then press the (FUNC SET) button.



4 Choose a layout.

- Press the ▲▼ buttons to choose a layout, then press the (FUNC SET) button.
- Press the ◀▶ buttons to set the number of prints when [N-up] is chosen.

5 Print.

Available Layout Options

Default	Follows the printer's settings.
Bordered	Prints with a border.
Borderless	Prints without a border.
N-up	Choose how many copies of an image are printed on a sheet.
ID Photo	Prints ID photos. Only images with the same resolution as the camera's L (Large) recording pixel setting can be chosen.
Fixed Size	Choose the print size. Choose from 3.5 x 5 in., postcard and wide sized prints.

Printing ID Photos

1 Choose [ID Photo].

- Follow Steps 1 – 4 on p. 136 to choose [ID Photo], then press the (FUNC SET) button.



2 Choose the length of the long side and short side.

- Press the ▲▼ buttons to choose an item.
- Press the ◀▶ buttons to choose the length, then press the (FUNC SET) button.



3 Choose the printing area.

- Follow Step 2 on p. 135 to choose the printing area.

4 Print.

Printing Movies



1 Connect the camera to the printer.

- Follow Steps 1 – 5 on p. 132 to choose a movie.
- Press the ◀▶ buttons to choose 🖨, then press the (FUNC SET) button to display the screen on the left.

2 Choose a printing method.

- Press the ▲▼ buttons to choose 🖼, then press the ◀▶ buttons to choose a printing method.

3 Print.

Printing methods for movies

Single	Prints currently displayed scene as a still image.
Sequence	Prints a sequence of images from a specified scene on a single sheet of paper. If [Caption] is set to [On], you can print the folder number, file number, and the elapsed time for the frame at the same time.

- Pressing the (FUNC SET) button during printing will cancel printing.
- [ID Photo] and [Sequence] cannot be chosen on Canon-brand PictBridge compliant printers from CP720/CP730 and earlier models.

Choosing Images for Printing (DPOF)

You can choose up to 998 images on a memory card for printing and specify settings such as the number of copies so that they can be printed together (p. 142) or processed at a photo developer service. These selection methods comply with the DPOF (Digital Print Order Format) standards.

Movies cannot be chosen.

Print Settings

You can set the print type, date and file number. These settings apply to all images chosen for printing.



1 Choose [Print Settings].

- Press the MENU button to choose [Print Settings] from the tab, then press the (FUNC. SET) button.

2 Adjust the settings.

- Press the ▲▼ buttons to choose a menu item, then press the ◀▶ buttons to choose an option.
- Press the MENU button to complete the setting and restore the menu screen.

Print Type	Standard	Prints 1 image per page.
	Index	Prints several reduced size images per page.
	Both	Prints both standard and index formats.
Date	On	Prints the shooting date.
	Off	—
File No.	On	Prints the file number.
	Off	—
Clear DPOF data	On	Removes all print settings after printing.
	Off	—

- Some printers or photo developer services may not be able to reflect all of the settings in the prints.
- ! may appear when using a memory card with print settings set by a different camera. These settings will be overwritten with those set by your camera.
- If [Date] is set to [On], some printers may print the date twice.

- With [Index] chosen, the [Date] and [File No.] options cannot be set to [On] at the same time.
- The date will be printed in the style set in the [Date/Time] function in the tab, which can be chosen after you press the MENU button (p. 18).

Choosing the Number of Copies



1 Choose [Select Images & Qty.].

- Press the MENU button to choose [Select Images & Qty.] from the tab, then press the (FUNC SET) button.

2 Choose an image.

- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- ▶ You will be able to set the number of print copies.
- If you choose images in [Index], ✓ appears on the screen. Press the (FUNC SET) button again to deselect the image. ✓ will disappear.



3 Set the number of prints.

- Press the ▲▼ buttons to set the number of prints (maximum 99).
- Repeat Steps 2 and 3 to choose other images and the number of prints for each.
- You cannot set the number of copies for index prints. You can only choose which images to print (as shown in Step 2).
- Press the MENU button to complete the setting and restore the menu screen.

Select Range



1 Choose [Select Range].

- Follow Step 1 on p. 140 to choose [Select Range], then press the (FUNC SET) button.

2 Choose images.

- Follow Steps 2 and 3 on p. 118 to choose images.

3 Make print settings.

- Press the ▲▼ buttons to choose [Order], then press the (FUNC SET) button.

Set All Images to Print Once



1 Choose [Select All Images].

- Follow Step 1 on p. 140 to choose [Select All Images], then press the (FUNC SET) button.

2 Make print settings.

- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.

Clearing All Selections



1 Choose [Clear All Selections].

- Follow Step 1 on p. 140 to choose [Clear All Selections], then press the (FUNC SET) button.

2 All selections will be cleared.

- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button.

Printing chosen images (DPOF)



- When there are images added to the print list (pp. 139 – 141), the screen on the left will appear when you connect the camera to a PictBridge compliant printer. Press the ▲▼ buttons to choose [Print now], then press the (FUNC SET) button to easily print images added to the print list.
- If you stop the printer during printing and start again, it will start from the next print.

9

Customizing Camera Settings

You can customize various settings to suit your shooting preferences. The first part of this chapter explains convenient and commonly used functions. The latter part explains how to change shooting and playback settings to suit your purposes.




Changing Camera Settings

You can customize convenient and commonly used functions from the tab (p. 46).

Changing Sounds

You can change each of the camera's operation sounds.



- Choose [Sound Options], then press the (FUNC SET) button.
- Press the ▲▼ buttons to choose a menu item.
- Press the ◀▶ buttons to choose an option.

1	Preset sounds (cannot be modified)
2	Preset sounds You can use the included software to change the sounds (p. 2).

You cannot change the sound settings in .

Turning Off Hints & Tips


When you choose an item in the FUNC. menu (p. 45) or MENU (p. 46), a description of the function (hints and tips) is displayed. You can turn off this function.



- Choose [Hints & Tips], then press the ◀▶ buttons to choose [Off].


Low Level Memory Card Formatting

Perform low level formatting when [Memory card error] appears, the camera does not operate properly, you think that the recording/reading speed of a memory card has dropped, or recording suddenly stops while shooting a movie. As you cannot retrieve the erased data, exercise adequate caution before formatting the memory card.



1 Choose [Low Level Format].

- Choose [Format], then press the (FUNC SET) button.
- Press the ▲▼ buttons to choose [Low Level Format], then press the ◀▶ buttons to display ✓.
- Press the ▲▼◀▶ buttons to choose [OK], then press the (FUNC SET) button.



2 Start the low level format.

- Press the ▲▼ buttons to choose [OK], then press the (FUNC SET) button.
- ▶ Low level formatting starts.
- ▶ When low level formatting ends, [Memory card formatting complete] will appear on the screen.

3 Complete the low level format.

- Press the (FUNC SET) button.

- Low level formatting may take longer than standard formatting (p. 21), since all recorded data is erased.
- You can stop a low level format of a memory card by choosing [Stop]. When stopping low level formatting, the data will be erased but the memory card can be used without problem.

Changing the Start-up Screen

You can change the start-up screen that appears when you turn on the camera.



- Choose [Start-up Image], then press the (FUNC SET) button.
- Press the ◀▶ buttons to choose an option.

☐×	No start-up image
1	Preset images (cannot be modified)
2	Preset images You can set recorded images, and use the included software to change the images.

Registering Recorded Images as the Start-up Screen

When you press the ▶ button and set the camera to Playback mode, you can register an image.



- Choose [Start-up Image], then press the (FUNC SET) button.
- Press the ◀▶ buttons to choose [2], then press the (FUNC SET) button.



- Press the ◀▶ buttons to choose an image, then press the (FUNC SET) button.
- Press the ◀▶ buttons to choose [OK], then press the (FUNC SET) button to complete registration.

Any previously registered start-up image will be overwritten when registering a new start-up image.

Register the start-up image or sounds with the included software

The dedicated operation sounds and start-up images on the included software can be registered to the camera. Refer to the *Software Guide* for details.

Changing the File Number Assignment

Images you shoot are automatically assigned file numbers in the order they were taken, from 0001 – 9999, and saved to folders of up to 2,000 images. You can change the file number assignment.



- Choose [File Numbering], then press the ◀▶ buttons to choose an option.

Continuous	Even if you shoot using a new memory card, the file numbers are assigned consecutively until an image with the number 9999 is taken/saved.
Auto Reset	If you replace the memory card with a new one, or a new folder is created, file numbering begins with 0001 again.

- If you use a memory card already containing images, the newly assigned file numbers may continue the existing numbering for both [Continuous] and [Auto Reset]. If you want to start over with file number 0001, format the memory card before use (p. 21).
- Refer to the *Software Guide* for information regarding folder structure or image types.

Creating Folders by Shooting Date

Images are saved into folders created each month, however, you can also create folders by shooting date.



- Choose [Create Folder], then press the ◀▶ buttons to choose [Daily].
- Images will be saved into folders created on each shooting date.

Changing the Lens Retract Time

For safety reasons, the lens retracts about 1 minute after pressing the ▶ button when in a Shooting mode (p. 26). If you want the lens to retract immediately when you press the ▶ button, set the retract time to [0 sec.].



- Choose [Lens Retract], then press the ◀▶ buttons to choose [0 sec.].

Turning Off the Power Saving Function

You can set the power saving function (p. 51) to [Off]. Setting it to [On] is recommended to save battery power.



- Choose [Power Saving], then press the (FUNC SET) button.
- Press the ▲▼ buttons to choose [Auto Power Down], then press the ◀▶ buttons to choose [Off].
- If you set the power saving function to [Off], be sure to turn the camera off after use.

Setting the Screen Shut-Off Time

You can adjust the time the screen takes to shut off automatically (p. 51). This also works when [Auto Power Down] is set to [Off].



- Choose [Power Saving], then press the (FUNC SET) button.
- Press the ▲▼ buttons to choose [Display Off], then use the ◀▶ buttons to choose a time.
- In order to save battery power, you should choose less than [1 min.].

Using the World Clock

When traveling abroad, you can record images with local dates and times simply by switching the time zone setting. If you pre-register the destination time zones, you can enjoy the convenience of not having to switch the Date/Time settings.



1 Set the home time zone.

- Choose [Time Zone], then press the (FUNC SET) button.
- When setting this for the first time, check the information that displays on the screen at the left, then press the (FUNC SET) button.




- Press the ◀▶ buttons to choose the home time zone.
- To set daylight saving time (adds 1 hour), press the ▲▼ buttons to choose ☀.
- Press the (FUNC SET) button.



2 Set the world time zone.

- Press the ▲▼ buttons to choose [✈ World], then press the (FUNC SET) button.
- Press the ◀▶ buttons to choose the world time zone.
- You can also set the daylight saving time as in Step 1.
- Press the (FUNC SET) button.



3 Choose the world time zone.

- Press the ▲▼ buttons to choose [✈ World], then press the MENU button.
- ▶ ✈ will appear on the shooting screen (p. 163).

If you change the date or time in the ✈ setting (p. 18), your [Home] time and date will automatically change.


Changing Shooting Function Settings

If you set the mode dial to **P**, you can change the settings in the 📷 tab (p. 46).

Before attempting to shoot using a function explained in this section in modes other than **P**, check if the function is available in those modes (pp. 168 – 175).

Turning Off the AF Assist Beam


The lamp will automatically light to assist focusing in low light conditions when you press the shutter button halfway. You can turn off the lamp.



- Choose [AF-assist Beam], then press the ◀▶ buttons to choose [Off].

Turning Off the Red-Eye Reduction Function

The red-eye reduction lamp lights in order to reduce the red-eye effect that occurs when shooting in dark conditions with the flash. You can turn off this function.



- Choose [Flash Settings], then press the (FUNC. SET) button.
- Press the ▲▼ buttons to choose [Red-Eye Lamp], then press the ◀▶ buttons to choose [Off].

Changing the Image Display Time Right After Shooting

You can change the length of time the images display right after shooting.



- Choose [Review], then press the ◀▶ buttons to choose an option.

2 – 10 sec.	Displays images for the set time.
Hold	The image displays until you press the shutter button halfway.
Off	Images will not display.

Changing the Way the Image Displays Right After Shooting

You can change the way the image displays right after shooting.




- Choose [Review Info], then press the ◀▶ buttons to choose an option.

Off	Displays the image only.
Detailed	Displays detailed information (p. 165).
Focus Check	The area inside the AF frame is magnified, allowing you to check the focus. The procedure is the same as in “Checking the Focus” (p. 113).

Displaying the Overlay

You can display grid lines for vertical and horizontal guidance, or a 3:2 guide to confirm the printable area for 3.5" x 5" and postcard size prints.



- Choose [Disp. Overlay], then press the ◀▶ buttons to choose an option.


Off	–
Grid Lines	A grid overlays the screen.
3:2 Guide	Gray bars appear on the top and bottom of the screen. This area will not print when printing on paper with a 3:2 aspect ratio.
Both	Both grid lines, and the 3:2 guide appear.

- In W, you cannot set [3:2 Guide] or [Both].
- Grid lines will not be recorded on the image.
- The gray areas displayed with [3:2 Guide] are the areas that will not be printed. The actual image recorded will include the portion in the gray areas.

Changing Playback Function Settings

You can adjust the settings in the ▶ tab by pressing the ▶ button (p. 46).

Choosing the Image that First Displays in Playback



- Choose [Resume], then press the ◀▶ buttons to choose an option.

Last seen	Resumes with the image last viewed.
Last shot	Resumes with the most recently shot image.

Turning off the Auto Rotate Function

When you play back images on the camera, images shot in vertical orientation automatically rotate and display vertically. You can turn off this function.



- Select [Auto Rotate], then press the ◀▶ buttons to select [Off].

- Images cannot be rotated (p. 125) if you have set [Auto Rotate] to [Off]. Rotated images will also appear in their original orientation.
- In Smart Shuffle (p. 114), even if [Auto Rotate] is set to [Off], images taken vertically will be displayed vertically, while rotated images will appear in their rotated orientation.

10

Useful Information


This chapter introduces how to use the AC adapter kit (sold separately), troubleshooting tips, and contains lists of functions and items that appear on the screen.

Replacing the Date/Time Battery


The life of the date/time battery (back-up battery) is approximately 7 years. If the Date/Time settings screen appears every time the camera is turned on, replace the date/time battery with a new one (CR1220).

1 **Turn off the camera.**

2 **Open the cover and remove the AA batteries (p. 14).**




3 **Remove the date/time battery holder.**



4 **Replace the battery.**

- Insert the battery with (+) and (-) sides oriented correctly.



5 **Insert the battery holder.**


6 **Insert the batteries and close the cover.**

7 **Turn on the camera and set the date/time (p. 18).**

Using Household Power


If you use AC Adapter Kit ACK800 (sold separately), you can use the camera without worrying about how much charge is left in the battery.

1 Turn off the camera.



2 Plug the cord into the camera.

- Open the cover and fully insert the plug into the camera.



3 Connect the power cord.

- Connect the power cord to the compact power adapter, then plug the other end into a power outlet.
- Turn the camera on to use it.
- After you finish, turn off the camera and unplug the power cord from the power outlet.

Do not unplug the plug or power cord with the camera turned on. This could erase images you have taken or damage the camera.

Troubleshooting

If you think there is a problem with the camera, first check the following. If the items below do not solve your problem, contact a Canon Customer Support Help Desk as listed on the included customer support list.

Power

You pressed the ON/OFF button, but nothing happened.

- Confirm that the batteries are the correct type, and is not depleted (p. 16).
- Confirm that the batteries are properly inserted (p. 15).
- Confirm that the memory card/battery cover is securely closed (p. 15).
- If the battery terminals are dirty, battery performance will decrease. Clean the terminals with a cotton swab and re-insert the batteries several times.

Batteries are consumed quickly.

- Battery performance decreases at low temperatures. Warm the batteries, for example, by placing them in your pocket, taking care that the terminals do not come into contact with any metal objects.

Lens will not retract.

- Do not open the memory card/battery cover while the power is on. After closing the memory card/battery cover, turn the power on then back off (p. 15).

TV output

Image is distorted or not showing on TV (p. 116).

Shooting

Cannot shoot.

- Set the mode dial to a Shooting mode (p. 41).
- When in Playback mode (p. 20), press the shutter button halfway (p. 22).

The screen is off (p. 25).

Screen does not display properly in dark places (p. 44).

Screen does not display properly while shooting.

Please note, the following will not be recorded in still images, but will be recorded in movies.

- When the camera is subjected to powerful light sources, the display may darken.
- When shooting under fluorescent or LED lighting, the screen may flicker.
- When shooting bright light sources, a bar of light (purplish red) may appear on the screen.

The screen turns off and you cannot shoot when you press the shutter button (p. 25).

appears when the shutter button is pressed halfway (p. 54).

- Set the flash to (p. 81).
- Increase the ISO speed (p. 83).
- Attach the camera to a tripod.

Image is blurred.
- Press the shutter button halfway to focus on the subject, then press fully to shoot (p. 22).
- Shoot the subject within the focusing distance (p. 178).
- Set the [AF-assist Beam] to [On] (p. 151).
- Confirm that functions which you do not intend to use (macro, etc.) are not set.
- Shoot using the focus lock or AF lock (pp. 89, 92).

Even when you press the shutter button halfway, the AF frame does not appear, and the camera does not focus.
- If you center on the light and dark contrasting area of the subject and push the shutter button halfway, or repeatedly push the shutter button halfway, the AF frame will appear and the camera will focus.

Subject is too dark.
- Set the flash to ϟ (p. 81).
- Correct the brightness with exposure compensation (p. 81).
- Adjust the image with i-Contrast (pp. 84, 129).
- Use spot metering or AE Lock to shoot (pp. 95, 96).

Subject is too bright (overexposed).
- Set the flash to ⊗ (p. 54).
- Correct the brightness with exposure compensation (p. 81).
- Use spot metering or AE Lock to shoot (pp. 95, 96).
- Reduce the light illuminating the subject.

Image is dark even though the flash fired (p. 25).
- Shoot within an appropriate distance for flash photography (p. 81).
- Increase the ISO speed (p. 83).

Image taken using the flash is too bright (overexposed).
- Shoot within an appropriate distance for flash photography (p. 81).
- Set the flash to ⊗ (p. 54).

White dots appear on the image when shooting with the flash.
- Light from the flash has reflected off dust particles or other objects in the air.

Image appears rough or grainy.
- Shoot with the ISO speed on a lower setting (p. 83).
- Depending on the Shooting mode, when shooting in a high ISO speed the image may appear rough or grainy (pp. 65, 66).

Eyes appear red (p. 98).
- Set the [Red-Eye Lamp] to [On] (p. 151). When shooting with the flash, the lamp (on the front of the camera) lights (p. 40), and for approximately 1 second while the camera is reducing red-eye, it is not possible to shoot. It is more effective if the subject is looking directly at the lamp. Even better results can be obtained by increasing the lighting in indoor settings or approaching closer to the subject.
- Correct images with red-eye correction (p. 130).

Recording images to the memory card takes a long time, or continuous shooting slows down.

- Perform a low-level format of the memory card in the camera (p. 145).

Cannot make settings for shooting functions or FUNC. menu.

- The items in which settings can be made differ depending on the shooting mode. Refer to “Functions Available in Each Shooting Mode” and “Shooting Menu” (pp. 168 – 175).

Cannot operate buttons.

- When the mode dial is set to 📷, some buttons cannot be used (p. 28).

Shooting movies

Correct shooting time does not display, or stops.

- Format the memory card in the camera, or use a memory card capable of recording at high speeds. Even when the shooting time does not display properly, the recorded video will be the length that it was actually shot (pp. 21, 30).

! appeared on the screen and shooting ended automatically.

The camera’s internal memory was insufficient. Try one of the following:

- Perform a low-level format of the memory card in the camera (p. 145).
- Change the image quality setting (p. 104).
- Use a memory card capable of recording at high speeds (p. 104).

Zoom does not operate (p. 106).

Playback

Cannot play back images or movies.

- If the file name or folder structure is changed on a computer, you may not be able to play back images or movies. Refer to the *Software Guide* for information regarding folder structure or file names.

Playback stops, or audio cuts out.

- Use a memory card that has had a low-level format performed on it with this camera (p. 145).
- If you copy a movie to a memory card that reads slowly, playback may interrupt momentarily.
- Depending on its capabilities, when playing movies on a computer, frames may drop or the audio may cut out.

Cannot operate buttons.

- When the mode dial is set to 📷, some buttons cannot be used (p. 28).

Computer

Cannot transfer images to a computer.

It may be possible to solve the problem when the camera is connected to a computer via cable by reducing the transfer speed.

- Press the ▶ button to enter Playback mode. Then press and hold the MENU button and press the ▲ and FUNC. SET buttons together. In the screen that appears, press the ◀▶ buttons to choose [B] and press the FUNC. SET button.

List of Messages That Appear on the Screen

If error messages appear on the screen, try one of the following solutions.

No memory card

- The memory card is not installed in the correct direction. Install the memory card in the correct direction (p. 15).

Memory card locked

- The SD memory card, SDHC memory card or SDXC memory card's write protect tab is set to "LOCK". Unlock the write protect tab (pp. 14, 15).

Cannot record!

- You attempted to shoot an image without a memory card. Install the memory card in the correct direction to shoot (p. 15).

Memory card error (p. 145)

- If the same message appears even when a formatted memory card is installed in the correct direction, contact a Canon Customer Support Help Desk (p. 15).

Insufficient space on card

- There is not enough free space on the memory card to shoot (pp. 23, 28, 29, 53, 79) or edit images (pp. 126 – 130). Erase the images (pp. 27, 120) to open space for new images, or insert an empty memory card (p. 15).

Change the batteries (p. 16)

No Image.

- There are no images recorded on the memory card that can be displayed.

Protected! (p. 117)

Unidentified Image/Incompatible JPEG/Image too large./Cannot play back AVI/RAW

- Unsupported images, or images with corrupted data cannot be displayed.
- Images manipulated on a computer, that have had their file name changed, or have been taken with a different camera may not display.

Cannot magnify!/Cannot play back this content in Smart Shuffle/Cannot rotate/Cannot modify image/Cannot register this image!/Cannot modify/ Cannot assign to category/Unselectable image.

- Incompatible images cannot be magnified (p. 114), played back in Smart Shuffle (p. 114), tagged as favorites (p. 122), rotated (p. 125), edited (pp. 126 – 130), registered to the start-up screen (p. 146), categorized (p. 123), or added to a print list (p. 139).
- Images manipulated on a computer, that have had their file name changed, or have been taken with a different camera may not be magnified, played back in Smart Shuffle, tagged as favorites, rotated, edited, registered to the start-up screen, categorized, or added to a print list.
- Movies cannot be magnified (p. 114), played back in Smart Shuffle (p. 114), edited (pp. 126 – 130), added to a print list (p. 139), or registered to the start-up screen (p. 146).

Invalid selection range

- When choosing the selection range (pp. 118, 121, 124, 141), you tried to choose a starting image that was after the last image or you tried to choose an ending image that was before the starting image.

Exceeded selection limit

- You chose more than 998 images in print settings. Choose less than 998 images (p. 140).
- Print settings could not be saved correctly. Reduce the number of selected images and try again (p. 140).
- You chose 501 or more images in Protect (p. 117), Erase (p. 120), Favorites (p. 122), My Category (p. 123) or Print Settings (p. 139).

Communication error

- Images could not be transferred to the computer or printed due to the large amount of images (approx. 1000) stored on the memory card. Use a commercially available USB card reader to transfer the images. Insert the memory card into the printer's card slot to print.

Naming error!

- The folder or image could not be created because there is an image with the same file name as the folder or image that the camera is attempting to create, or the highest possible file number has already been reached. In the menu, change [File Numbering] to [Auto Reset] (p. 147) or format the memory card (p. 21).

Lens Error

- This error can occur if you hold the lens while it is in motion or when using it in a location with excessive dust or sand in the air.
- If this error message continues to appear, contact a Canon Customer Support Help Desk as there may be a problem with the lens.

A camera error was detected (Error number)

- If an error code appears directly after taking a picture, the shot may not have been recorded. Check the image in Playback mode.
- If this error code reappears, note the Error number (Exx) and contact a Canon Customer Support Help Desk as there may be a problem with the camera.

File Error

- Photos from other cameras or images that have been altered using computer software may not be printable.

Print error


- Check the paper size settings. If this message appears when the settings are correct, turn the printer off and back on, then make the settings again.

Ink absorber full

- Contact a Canon Customer Support Help Desk for an ink absorber replacement.

Information Displayed on the Screen

Shooting (Information Display)



① Battery Charge Indicator (p. 16)
② Camera Orientation*
③ White Balance (p. 82)
④ My Colors (p. 86)
⑤ Drive Mode (p. 85)
⑥ Camera Shake Warning (p. 25)
⑦ Metering Method (p. 95)
⑧ Compression (Image Quality) (p. 61) / Recording Pixels (pp. 61, 104)
⑨ Still Images: Recordable Shots (p. 62)
Movies: Remaining Time (p. 104)
⑩ Self-Timer (pp. 58, 59, 60)
⑪ AF Frame (p. 88)
⑫ Spot AE Point Frame (p. 95)
⑬ Digital Zoom Magnification (p. 55) / Digital Tele-converter (p. 56)
⑭ Focusing Range (p. 87), AF Lock (p. 92)
⑮ Shooting Mode (p. 168), Scene Icon (p. 164)
⑯ Flash Mode (pp. 54, 81, 97)
⑰ Red-Eye Correction (p. 130)
⑱ Time Zone (p. 149)
⑲ Date Stamp (p. 57)
⑳ ISO Speed (p. 83)
㉑ Grid Lines (p. 153)
㉒ AE Lock (p. 96), FE Lock (p. 96)
㉓ Shutter Speed
㉔ Aperture Value
㉕ Exposure Compensation Amount (p. 81)
㉖ 3:2 Guide (p. 153)
㉗ i-Contrast (p. 84)
㉘ Exposure Shift Bar (p. 105)
㉙ Zoom Bar (p. 23)
㉚ Blink Detection (p. 99)

* : Standard, : Held vertically
When shooting, the camera detects if it is held vertically or horizontally, and adjusts settings accordingly for the best shot. It also detects orientation during playback, so you can hold the camera in either orientation and it will automatically rotate images for correct viewing. This function may not operate correctly when the camera is pointed straight up or down.


Scene Icons

In AUTO mode, the camera displays an icon for the scene it has determined and then automatically focuses and selects the optimum settings for subject brightness and color.

Subject / Background	People			Non-Human Subjects			Icon Background Color
		When Moving	With Strong Facial Shadows		When Moving	When Close	
Bright							Gray
Backlit			—				
Including Blue Skies							Light Blue
Backlit			—				
Sunsets	—					—	Orange
Spotlights							Dark Blue
Dark							
When Using Tripod	*	—		*	—		

* Appears when the scene is dark and the camera is attached to a tripod.

Playback (Detailed Information Display)



① My Category (p. 123)
② Shooting Mode (p. 168)
③ ISO Speed (p. 83)
④ Exposure Compensation Amount (p. 81), Exposure Shift Amount (p. 105)
⑤ White Balance (p. 82)
⑥ Histogram (p. 44)
⑦ Compression (Image Quality) (p. 61) / Recording Pixels (pp. 61, 104), MOV (Movies)
⑧ Battery Charge Indicator (p. 16)
⑨ Metering Method (p. 95)
⑩ Folder Number – File Number (p. 147)
⑪ Displayed image number / Total number of images
⑫ Shutter Speed
⑬ Aperture Value, Image Quality (Movies) (p. 104)
⑭ Flash (p. 81)
⑮ i-Contrast (pp. 84, 129)
⑯ Focusing Range (p. 87)
⑰ File Size (pp. 62, 104)
⑱ Still Images: Recording Pixels (p. 61) Movies: Movie Length (p. 104)
⑲ Image Editing (pp. 126 – 130)
⑳ Protect (p. 117)
㉑ Favorites (p. 122)
㉒ My Colors (p. 86)
㉓ Red-Eye Correction (pp. 98, 130)
㉔ Shooting Date and Time (p. 18)

Summary of Movie Control Panel in “Viewing Movies” (p. 31)

⮌	Exit
▶	Playback
▶|	Slow motion playback (You can use the ◀▶ buttons to adjust the speed. Sound will not play back.)
|◀◀	Skip backward* (Continues to skip backward if button is held.)
◀||	Previous frame (Rewind if you hold down the FUNC SET button.)
||▶	Next frame (Fast forward if you hold down the FUNC SET button.)
▶▶|	Skip forward* (Continues to skip forward if button is held.)
✂	Edit (p. 107)
🖶	Appears when connected to a PictBridge compliant printer (p. 132).

* Displays the frame of approx. 4 sec. before or after the current frame.

You can skip forward and skip backward during movie playback by pressing the ◀▶ buttons.

Handling Precautions

- This camera is a high-precision electronic device. Do not drop it or subject it to strong impacts.
- Never place the camera close to magnets, motors or other devices that generate strong electromagnetic fields. Exposure to strong magnetic fields may cause malfunctions or corrupt image data.
- If water droplets or dirt become stuck on the camera or screen, wipe with a dry soft cloth or eyeglass wiper. Do not rub or apply force.
- Never use cleaners containing organic solvents to wipe the camera or screen.
- Use a commercially available blower brush to remove dust from the lens. For stubborn dirt contact a Canon Customer Support Help Desk as listed in your Warranty System Booklet.
- When you move the camera rapidly from cold to hot temperatures, condensation may form on the internal or external surfaces of the camera. To avoid condensation, put the camera in an airtight, resealable plastic bag and let it adjust to temperature changes slowly before removing it from the bag.
- If condensation has formed on the camera, stop using it immediately, as continued use may damage the camera. Remove the batteries and memory card, and wait until the moisture has completely evaporated before resuming use.

Functions Available in Each Shooting Mode

Function \ Shooting modes		P	LIVE	AUTO		SCN			
Exposure Compensation (p. 81)		O	*1	—	—	O	O	O	O
Self-Timer (pp. 58, 59, 60)	Off	O	O	O	O	O	O	O	O
	10	O	O	O	—	O	O	O	O
	2	O	O	O	—	O	O	O	O
	Custom	O	O	O	—	O	O	O	O
Custom Timer (p. 60)	Delay *2	O	O	O	—	O	O	O	O
	Shots *3	O	O	O	—	O	O	O	O
Flash (pp. 54, 81, 97)	A	O	O	O	O	O	O	O	O
		O	O	—	—	O	O	O	O
		O	O	*4	*4	—	—	*5	—
		O	O	O	O	O	O	O	O
AE Lock/FE Lock (p. 96) *6		O	—	—	—	—	—	—	—
AE Lock/Exposure Shift (Movies) (p. 105)		—	—	—	—	—	—	—	—
AF Lock (p. 92)		O	O	—	—	—	—	—	—
Focusing Range (p. 87)		O	O	O	O	O	O	O	O
		O	O	—	—	O	O	O	—
		O	O	—	—	O	O	O	—
Face Select (p. 94)		O	O	O	—	O	O	O	O
Screen Display (p. 43)	Off	O	—	O	—	O	O	O	O
	No Information Display	O	O	O	—	O	O	O	O
	Information Display	O	O	O	O	O	O	O	O

*1 Set in [Dark] and [Light].
*2 Cannot be set to 0 seconds when in modes where the number of shots cannot be set.
*3 Fixed to 1 shot when in modes where the number of shots cannot be set.
*4 Cannot be set, but switches to depending on the circumstances.
*5 Cannot be set, but switches to when the flash fires.
*6 FE Lock not available when set to .

SCN																		
O	O	O	O	O	O	O	O	—	O	O	O	O	O	—	O	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
—	—	—	O	O	O	O	O	O	O	O	O	O	O	O	—	O	O
—	—	—	O	O	O	O	O	O	O	O	O	O	O	O	—	O	O
—	—	—	O	O	O	O	O	O	O	O	O	O	O	O	—	O	O
—	—	—	O	O	O	O	O	O	O	O	O	O	O	O	—	O	O
—	—	—	O	O	O	O	O	O	O	O	O	O	O	O	—	—	—
O	O	O	O	O	O	O	—	—	O	O	O	O	O	O	—	—	—
O	O	O	—	O	O	O	—	O	O	O	O	O	O	O	—	—	—
—	—	—	—	—	—	—	—	*5	—	—	—	—	—	—	—	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	O	—
—	—	—	—	—	—	—	—	O	—	—	—	—	—	—	—	O	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
—	—	—	O	O	O	O	—	O	O	O	O	O	O	O	O	O	O
—	—	—	O	O	O	O	—	O	O	O	O	O	O	O	O	O	O
O	O	O	O	O	O	O	—	O	—	—	O	O	O	O	O	—	—
—	—	—	O	O	O	O	O	O	—	—	—	—	—	—	O	—	—
—	—	—	O	O	O	O	O	O	—	—	—	—	O	O	O	O	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O

O Selectable, or set automatically. – Not selectable.

FUNC. Menu									
Function \ Shooting modes		P	LIVE	AUTO		SCN			
ISO Speed (p. 83)	ISO AUTO	○	○	○	○	○	○	○	○
	ISO 80	○	—	—	—	—	—	—	—
	ISO 100	○	—	—	—	—	—	—	—
	ISO 200	○	—	—	—	—	—	—	—
	ISO 400	○	—	—	—	—	—	—	—
	ISO 800	○	—	—	—	—	—	—	—
	ISO 1600	○	—	—	—	—	—	—	—
White Balance (p. 82)	AWB	○	○	○	○	○	○	○	○
	☀	○	—	—	—	○	—	—	—
	☁	○	—	—	—	○	—	—	—
	💡	○	—	—	—	○	—	—	—
	💡	○	—	—	—	○	—	—	—
	💡	○	—	—	—	○	—	—	—
	🖋	○	—	—	—	○	—	—	—
My Colors (p. 86)	MY OFF	○	○	○	○	○	○	○	○
	MY V	○	—	—	—	—	—	—	—
	MY N	○	—	—	—	—	—	—	—
	MY Se *7	○	—	—	—	—	—	—	—
	MY BW *7	○	—	—	—	—	—	—	—
	MY C *8	○	—	—	—	—	—	—	—
Drive Mode (p. 85)	□	○	○	○	○	○	○	○	○
	▣	○	—	—	—	○	○	○	○
Metering Method (p. 95)	◉	○	○	○	○	○	○	○	○
	▢	○	—	—	—	—	—	—	—
	⊙	○	—	—	—	—	—	—	—
Recording Pixels (p. 61)	L	○	○	○	○	—	○	○	○
	M1	○	—	○	—	—	○	○	○
	M2	○	—	○	—	—	○	○	○
	M	—	—	—	—	○	—	—	—
	S	○	—	○	—	—	○	○	○
	W	○	—	○	—	—	○	○	○
Compression Ratio (Image Quality) (p. 61)	◢	○	○	○	○	○	○	○	○
	▟	○	—	○	—	○	○	○	○
Image Quality (Movies) (p. 104)	1280	—	—	—	—	—	—	—	—
	640	—	—	—	—	—	—	—	—
	320	—	—	—	—	—	—	—	—

*7 White balance is not selectable. *8 Contrast, sharpness and color saturation can be set in 5 levels.

FUNC. Menu																		
SCN																		
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	○	—	—	—	—	—	—	—	—	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
○	○	○	—	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	—	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	—	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	—	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	—	—	—	—	—	○	—	—	—	—	—	—	○	○	○	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	—	○	○	○	○	○	—	○	○	○	○	○	○	○	○	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
○	○	○	—	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	○	—	—
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	○	—	—
—	—	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	○	—	—
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	○	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	○
—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	○	—

○ Selectable, or set automatically. – Not selectable.

Shooting Menu

Function \ Shooting Modes			P	LIVE	AUTO		SCN			
AF Frame (p. 88)	Face AiAF *1		○	○	○	○	○	○	○	○
	Tracking AF		○	○	*2	—	○	○	○	○
	Center		○	○	—	—	○	○	○	○
AF Frame Size (p. 89) *3	Normal		○	○	—	—	○	○	○	○
	Small		○	○	—	—	○	○	○	○
Digital Zoom (p. 55)	Standard		○	○	○	○	—	○	○	○
	Off		○	○	○	—	○	○	○	○
	1.5x		○	○	○	—	—	○	○	○
	2.0x		○	○	○	—	—	○	○	○
AF-Point Zoom (p. 91)	On		○	○	○	—	○	○	○	—
	Off		○	○	○	○	○	○	○	○
Servo AF (p. 93)	On		○	○	—	—	○	○	○	○
	Off *4		○	○	○	○	○	○	○	—
AF-assist Beam (p. 151)	On		○	○	○	*5	○	○	○	○
	Off		○	○	○	—	○	○	○	○
Flash Settings (pp. 98, 151)	Red-Eye Corr.	On	○	—	○	—	○	○	○	○
		Off	○	○	○	○	○	○	○	○
	Red-Eye Lamp	On	○	○	○	○	○	○	○	○
		Off	○	○	○	—	○	○	○	○
i-Contrast (p. 84)	Auto		○	—	○	○	—	—	—	—
	Off		○	○	—	—	○	○	○	○
Review (p. 152)	Off		○	○	○	—	○	○	○	○
	2 sec.		○	○	○	○	○	○	○	○
	– 10 sec.		○	○	○	—	○	○	○	○
	Hold		○	○	○	—	○	○	○	○
Review Info (p. 152)	Off		○	○	○	○	○	○	○	○
	Detailed		○	○	○	—	○	○	○	○
	Focus Check		○	○	○	—	○	○	○	○
Blink Detection (p. 99)	On		○	○	○	—	○	○	○	○
	Off		○	○	○	○	○	○	○	○

*1 Operation differs depending on the shooting mode when faces are not detected.
*2 Only available by pressing ▲ button (p. 25).
*3 Available when the AF frame is set to [Center].
*4 [On] when moving people are detected in AUTO.
*5 [On] when the flash is set to ϟ^{A}.

SCN																			
○	○	○	○	○	○	○	—	○	—	—	○	○	○	○	○	○	○	—
—	—	—	○	○	○	○	—	○	—	—	—	○	○	○	○	—	—	
—	—	—	○	○	○	○	○	○	○	—	○	○	○	○	○	—	—	
—	—	—	○	○	○	○	○	○	○	—	○	○	○	○	○	—	—	
—	—	—	○	○	○	○	—	○	—	—	○	○	○	○	○	—	—	
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	○	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	—	—	
○	○	○	—	○	○	○	○	○	—	—	—	○	○	○	○	—	—	
○	○	○	○	○	○	○	—	○	—	—	—	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
—	—	—	○	○	○	○	—	—	—	—	—	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
○	○	○	○	○	○	○	—	○	○	○	○	○	○	○	—	○	○	
—	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
○	○	○	○	○	○	○	—	○	—	—	—	—	—	—	—	—	—	
○	○	○	○	○	○	○	—	○	○	○	○	○	○	○	—	—	—	
○	○	○	○	○	○	○	—	○	○	○	○	○	○	○	—	—	—	
○	○	○	○	○	○	○	—	○	○	○	○	○	○	○	—	—	—	
—	—	—	○	—	—	—	—	—	—	—	—	—	—	—	—	—	—	
○	○	○	—	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	—	—	
○	○	○	○	○	○	○	—	—	—	—	—	—	○	○	○	—	—	
○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	

○ Selectable, or set automatically. – Not selectable.

Function	Shooting Modes	P	LIVE	AUTO		SCN			
Disp. Overlay (p. 153)	Off	○	○	○	○	○	○	○	○
	Grid Lines	○	○	○	—	○	○	○	○
	3:2 Guide	○	○	○	—	○	○	○	○
	Both	○	○	○	—	○	○	○	○
Date Stamp (p. 57)	Off	○	○	○	○	○	○	○	○
	Date	○	○	○	—	○	○	○	○
	Date & Time	○	○	○	—	○	○	○	○

SCN																	
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	—	—
O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
O	O	O	—	O	O	O	O	O	—	—	—	—	—	—	O	—	—
O	O	O	—	O	O	O	O	O	—	—	—	—	—	—	O	—	—

O Selectable, or set automatically. – Not selectable.

Set up Menu

Item	Content	Ref. Page
Mute	On/Off*	p. 47
Volume	Set all operation sounds (5 levels).	p. 48
Sound Options	Set the sounds for each camera operation.	p. 144
Hints & Tips	On*/Off	p. 144
LCD Brightness	Sets screen brightness (5 levels).	p. 49
Start-up Image	Add an image as a start-up image.	p. 146
Format	Formats memory card, erasing all data	pp. 21, 145
File Numbering	Continuous*/Auto Reset	p. 147
Create Folder	Monthly*/Daily	p. 148
Lens Retract	1 min.*/0 sec.	p. 148
Power Saving	Auto Power Down: On*/Off Display Off: 10, 20 or 30 sec./1*, 2 or 3 min.	pp. 51, 148, 149
Time Zone	Home*/World	p. 149
Date/Time	Date and time settings	p. 19
Video System	NTSC/PAL	p. 116
Language	Choose display language.	p. 20
Reset All	Returns camera to default settings.	p. 50

* Default setting

Playback Menu

Item	Content	Ref. Page
Smart Shuffle	Starts Smart Shuffle.	p. 114
Slideshow	Plays back images automatically.	p. 112
Erase	Erases images (Select, Select Range, All Images).	p. 120
Protect	Protects images (Select, Select Range, All Images).	p. 117
Rotate	Rotates images.	p. 125
Favorites	Tags or untags images as favorites.	p. 122
My Category	Categorizes images (Select, Select Range).	p. 123
i-Contrast	Corrects dark portions and contrast in still images.	p. 129
Red-Eye Correction	Corrects red eyes in still images.	p. 130
Trimming	Trims portions of still images.	p. 127
Resize	Resizes and saves still images.	p. 126
Scroll Display	On*/Off	p. 110
Auto Rotate	On*/Off	p. 154
Resume	Last seen*/Last shot	p. 154
Transition	Fade*/Scroll/Slide/Off	p. 115

* Default setting

Print Menu

Item	Content	Ref. Page
Print	Displays printing screen (When connected to a printer).	—
Select Images & Qty.	Chooses individual images for printing.	p. 140
Select Range	Chooses starting and ending images for printing.	p. 141
Select All Images	Chooses all images for printing.	p. 141
Clear All Selections	Cancels all settings for printing.	p. 141
Print Settings	Sets the printing style.	p. 139

Specifications

Image Sensor
- Camera Effective Pixels ..... Approx. 12.1 million pixels

Lens
- Focal Length ..... 4x zoom: 5.0 (W) – 20.0 (T) mm (35mm film equivalent: 28 (W) – 112 (T) mm)
- Focusing Range ..... 3 cm (1.2 in.) – infinity (W), 80 cm (2.6 ft.) – infinity (T)
  - Macro 3 – 50 cm (W) (1.2 in. – 1.6 ft. (W))

Imaging Processor ..... DIGIC 4

Optical Viewfinder ..... Real-image zoom viewfinder

LCD Monitor
- Type ..... TFT color (wide viewing angle type)
- Size ..... 6.8 cm (2.7 in.)
- Effective Pixels ..... Approx. 230,000 dots
- Aspect Ratio 4:3
- Features ..... Brightness adjustment (5 levels)

Focus
- Control System ..... Autofocus: Single (Continuous in Auto mode)
- AF Frame ..... Face AiAF, Tracking AF, Center

Metering System ..... Evaluative, Center-weighted average, Spot

Exposure Compensation (Still Images)/
Exposure Shift (Movies) ..... ±2 stops in 1/3-stop increments

ISO Speed (Standard Output Sensitivity,
Recommended Exposure Index) ..... Auto, ISO 80/100/200/400/800/1600

White Balance ..... Auto, Day Light, Cloudy, Tungsten, Fluorescent, Fluorescent H, Custom

Shutter Speed ..... 1 – 1/1600 sec.
15 – 1/1600 sec. (Total shutter speed range)

Aperture
- Type ..... Circular (Used together with ND filter)
- f/number ..... f/2.8 / f/8.0 (W), f/5.9 / f/17 (T)

Flash
- Modes ..... Auto, On, Slow Synchro, Off
- Range ..... 30 cm – 4.0 m (W), 50 cm – 2.0 m (T)
  (12 in. – 13 ft. (W), 1.6 – 6.6 ft. (T))

Shooting Modes.....P, Live View Control, Auto, Easy, SCN*1, Creative Filters*2, Discreet, Movie*3
*1 Blur Reduction, Portrait, Landscape, Kids&Pets, Smart Shutter*4, Low Light, Beach, Foliage, Snow, Fireworks, Long Shutter
*2 Fish-eye Effect, Miniature Effect, Toy Camera Effect, Monochrome, Super Vivid, Poster Effect
*3 Standard, Miniature Effect
*4 Smile, Wink Self-timer, Face Self-timer

Digital Zoom .....Still images/Movies: Approx. 4.0x (up to approx. 16x in combination with the optical zoom)
Safety Zoom, Digital tele-converter

Continuous Shooting
Mode .....Normal
Speed (Normal).....Approx. 1.0 shots/sec. (In P mode)
Approx. 3.6 shots/sec. (In Blur Reduction and Low Light mode)

Number of Shots (Approximate)
(CIPA compliant) .....Alkaline: Approx. 200
NiMH: Approx. 450

Recording Media .....SD memory card, SDHC memory card, SDXC memory card, MultiMediaCard, MMC*plus* card, HC MMC*plus* card

File Format .....Design rule for Camera File system, DPOF (Version 1.1) compliant

Data Type
Still Images.....Exif 2.3 (JPEG)
Movies.....MOV (Image data: H.264; Audio data: Linear PCM (monaural))

Number of Recording Pixels
Still Images.....Large: 4000 x 3000, Medium 1: 2816 x 2112, Medium 2: 1600 x 1200, Small: 640 x 480, Widescreen: 4000 x 2248
Movies.....Standard: 1280 x 720 (24 fps*1), 640 x 480 (30 fps*2), 320 x 240 (30 fps*2)
Miniature Effect 1280 x 720*3, 640 x 480*3
*1 Actual frame rate is 23.976 fps
*2 Actual frame rate is 29.97 fps
*3 Shooting: 6 fps, 3 fps, 1.5 fps
Playback: 30 fps*2

Interface.....Hi-Speed USB
Analog audio output (monaural)
Analog video output (NTSC/PAL)

Direct Print Standard .....PictBridge

Power Source	AA alkaline batteries (AA NiMH batteries NB-3AH) x 2 Compact Power Adapter CA-PS800
Dimensions (CIPA compliant)	97.5 x 62.5 x 30.7 mm (3.84 x 2.46 x 1.21 in.)
Weight (CIPA compliant)	Approx. 185 g (6.53 oz.) (Including the battery and memory card) Approx. 137 g (4.83 oz.) (camera body only)

- All data is based on tests by Canon.
- Camera specifications or appearance are subject to change without notice.

Index

Numerics

3:2 Guide 153

A

AC Adapter Kit 157
Accessories 37
AE Lock 96, 105
AF Frames 24, 88
AF → Focus
AF Lock 92, 163
AF-Point Zoom 91
AUTO Mode (Shooting Mode) 23, 41
AV Cable 116

B

Batteries 14, 37
  Battery and Charger Kit 37
  Charge Indicator 16
  → Date/Time Battery
  Power Saving 51, 148, 149
Battery
  Power Saving 51, 148, 149
Battery and Charger Kit 37
Beach (Shooting Mode) 65
Black and White Images 86
Blink Detection 99
Blur Reduction (Shooting Mode) 64

C

Camera
  Default Settings 50
  Holding the Camera 13
Camera Shake 25, 54
Center (AF Frame Mode) 89
Clock Functions 51
Components Guide 40
Compression Ratio (Image Quality) 61
Continuous Shooting 85
Creative Filters (Shooting Mode) 68
Custom White Balance 82

D

Date and Time → Date/Time
Date/Time
  Adding to Image 57
  Changing 19
  Date/Time Battery 156
  Setting 18
  World Clock 149
Default Settings 50
DIGITAL CAMERA Solution Disk 2
Digital Tele-Converter 56
Digital Zoom 55
Discreet (Shooting Mode) 68
Display Language 20
DPOF 139
Drive Mode 85

E

Easy (Shooting/Playback Mode) 28
Editing
  i-Contrast 129
  Red-Eye Correction 130
  Resizing (Making Images Smaller) 126
  Trimming 127
Erasing All Images 120
Erasing Images 27, 120
Error Messages 161
Exposure
  AE Lock 96, 105
  Correction 81
  FE Lock 96
  Shift 105

F

Face AiAF (AF Frame Mode) 88
Face Select 94
Face Self-Timer (Shooting Mode) 76
Factory Settings → Default Settings
FE Lock 96, 163
File Numbering 147
Fireworks (Shooting Mode) 66
Fish-eye Effect (Shooting Mode) 69

Flash
Off....54
On....81
Slow Synchro....97
Focus
AF Frames....24, 88
AF Lock....92
AF-Point Zoom....91
Face Select....94
Servo AF....93
Focus Check....113
Focus Lock....89
Focusing Range
Infinity....87
Macro....87
Foliage (Shooting Mode)....65
Format → Memory Cards, Formatting
Formatting (Memory Card)....21, 145
FUNC. Menu
Basic Operations....45
List....168

G

Grid Lines....153, 163

H

Household Power....157

I

i-Contrast....84, 129
Image Quality → Compression Ratio
Images
Display Time....152
Editing → Editing
Erasing Images....27, 120
Playback → Viewing
Protect....117
Included Items → Accessories
Indicator....42, 44
Infinity (Focus Mode)....87
Interface Cable....2, 34, 132
ISO Speed....83, 163

J

Jump Display....111

K

Kids&Pets (Shooting Mode)....65

L

Lamp....40, 151
Landscape (Shooting Mode)....65
LCD Monitor → Screen
Live View Control (Shooting Mode)....67
Long Shutter (Shooting Mode)....77
Low Light (Shooting Mode)....65

M

Macro (Focus Mode)....87
Magnified Display....114
Memory Cards
Available Shots....16, 62
Formatting....21, 145
Shooting Time....30
MENU
Basic Operations....46
List....172
Metering Method....95
Miniature Effect (Shooting Mode)....70, 102
Monochrome (Shooting Mode)....72
Movies
Editing....107
Image Quality (Recording Pixels/
Frame Rate)....104
Modes....102
Shooting Time....16, 30
Viewing (Playback)....31
MultiMediaCard/MMC*plus* → Memory Cards
My Category....123
My Colors (Shooting)....86

P

P (Shooting mode)....80
PictBridge....38, 132
Playback → Viewing
Playback With Transition Effects....115
Portrait (Shooting Mode)....64
Poster Effect (Shooting Mode)....69

Power → Battery, AC Adapter Kit
Power Saving 51, 148, 149
Printing 132
Program AE (Shooting Mode) 80
Protect 117

R

Recording Pixels (Image Size) 61
Red-Eye Correction 98, 130
Resizing (Making Images Smaller) 126
Rotate 125

S

Screen
  Display Language 20
  Information Display 163, 165
  Menu → FUNC. Menu, MENU
  Switching the Display 43
SD/SDHC/SDXC Memory Card → Memory Cards
Self-Timer
  10 Second Self-Timer 58
  Changing Delay and Number of Shots 60
  Face Self-Timer (Shooting Mode) 76
  Two Second Self-Timer 59
  Wink Self-Timer (Shooting Mode) 74
Sepia Tones 86
Servo AF 93
Shooting
  Display Overlay 153
  Number of Shots 16, 62
  Shooting Date and Time → Date/Time
  Shooting Info 163
  Shooting Time 30
Shooting Using a TV 100
Slideshow 112
Smart Shuffle 114
Smart Shutter (Shooting Mode) 73
Smile (Shooting Mode) 73
Snow (Shooting Mode) 66
Software
  DIGITAL CAMERA Solution Disk 2
  Installation 33
  Software Guide 2
  Transferring Images to a Computer for Viewing 32
Sound Settings 47
Strap 13
Super Vivid (Shooting Mode) 69

T

Tag Images as Favorites 122
Terminal 34, 116, 132, 157
Toy Camera Effect (Shooting Mode) 71
Tracking AF 25, 90
Travel Abroad 37, 149
Trimming 127
Troubleshooting 158

V

Video → Movies
Viewfinder 100
Viewing
  Images on a TV 116
  Index Display 110
  Jump Display 111
  Magnified Display 114
  Scroll Display 110
  Single Image Playback 26
  Slideshow 112
  Smart Shuffle 114
Viewing Images on a TV 116

W

White Balance 82
Wide (Recording Pixels) 61, 62
Wink Self-Timer (Shooting Mode) 74
World Clock 149
Wrist Strap → Strap

Z

Zoom 23, 29, 55

Disclaimer

- Reprinting, transmitting, or storing in a retrieval system any part of this guide without the permission of Canon is prohibited.
- Canon reserves the right to change the contents of this guide at any time without prior notice.
- Illustrations and screenshots in this guide may differ slightly from the actual equipment.
- The above items notwithstanding, Canon accepts no liability for damages due to mistaken operation of the products.

CEL-SQ9LA210
© CANON INC. 2011